

## UNIT INFORMATION

Corp. 0205-L3 Revised April 2012

## CBX32M

### CBX32M (HFC-410A) SERIES UNIT



IT IS HIGHLY RECOMMENDED IF THE AIR HANDLER IS INSTALLED IN A UNCONDITIONED SPACE THAT A CIRCUIT BREAKER COVER (ORDERED SEPARATELY) IS USED. ORDER LENNOX CATALOG # 82W01.
OLDOUIT DDE AKED
CIRCUIT BREAKER OPENING
CIRCUIT BREAKER
COVER

## **WARNING**

Improper installation, adjustment, alteration, service or maintenance can cause personal injury, loss of life, or damage to property.

Installation and service must be performed by a licensed professional installer (or equivalent) or a service agency.

## **A CAUTION**

Physical contact with metal edges and corners while applying excessive force or rapid motion can result in personal injury. Be aware of, and use caution when working near these areas during installation or while servicing this equipment.

General	1
Specifications	2
Blower Data	3
Parts Arrangement	3
I Application	7
II Unit Components	7
III Optional Electric Heat Data 8	3
IV Configuration Modifications	22
V Start Up Operation	25
VI Typical Operating Characteristics	26
VII Maintenance	27

VIII Wiring Diagrams and Operating Sequence . . . . 28

**Table of Contents** 

#### General

CBX32M are high efficiency blower coils designed for R410A applications only. Several models are available in sizes ranging from 1-1/2 through 5 tons (5.3 through 17.6 kW). The CBX32M units are multi-position (upflow, downflow or horizontal). The units come with a factory installed check and expansion valve for cooling or heat pump applications.

CBX32M series units are designed to be matched with the 12 and 13 SEER air conditioner and heat pump lines. While these blower coil units are designed to be primarily matched with these outdoor units, they may be matched with other air conditioners or heat pumps as noted in the rating information.

ECB29 electric heat, in several voltages and kW sizes, can be field installed in the CBX32M cabinets.

Information contained in this manual is intended for use by qualified HVAC service technicians only. All specifications are subject to change. Procedures outlined in this manual are presented as a recommendation only and do not supersede or replace local or state codes.

## **AWARNING**



Electric shock hazard. Can cause injury or death. Before attempting to perform any service or maintenance, turn the electrical power to unit OFF at disconnect switch(es). Unit may have multiple power supplies.



### **Specifications**

General Data	Model Number	CBX32M -018/024	CBX32M -030	CBX32M -036	CBX32M -042	CBX32M -048	CBX32M -060
	Nominal Tonnage	1.5 - 2	2.5	3	3.5	4	5
	Refrigerant	R-410A	R-410A	R-410A	R-410A	R-410A	R-410A
Connections	Suction (vapor) line - sweat	5/8	3/4	3/4	7/8	7/8	7/8
in.	Liquid line - sweat	3/8	3/8	3/8	3/8	3/8	3/8
	Condensate drain - fpt	(2) 3/4	(2) 3/4	(2) 3/4	(2) 3/4	(2) 3/4	(2) 3/4
Evaporator	Net face area - ft. <sup>2</sup>	3.56	4.44	5.0	5.0	7.22	7.22
Coil	Tube outside diameter - in.	3/8	3/8	3/8	3/8	3/8	3/8
	Number of rows	3	3	3	3	3	3
	Fins per inch	12	12	12	12	12	12
Blower Data	Wheel nom. diameter x width - in.	10 x 7	10 x 8	11 x 8	11 x 8	11-1/2 x 9	12 x 9
	Blower motor output - hp	1/5	1/3	1/3	1/3	1/3	1/2
Filters	<sup>1</sup> Number	1	1	1	1	1	1
	Size - in.	15 x 20 x 1	20 x 20 x 1	20 x 22 x 1	20 x 22 x 1	20 x 24 x 1	20 x 24 x 1
Shipping Data	1 Package - Ibs.	136	157	177	181	206	206
ELECTRICAL D	ATA						
	Voltage - 1 phase	208/230V	208/230V	208/230V	208/230V	208/230V	208/230V
	Voltage - 3 phase			<sup>3</sup> 460V		<sup>3</sup> 460V	<sup>3</sup> 460V
<sup>2</sup> Maxi	mum overcurrent protection (unit only) all voltages	15	15	15	15	15	15
Minimum	circuit ampacity (unit only) - 208/230V	2	2	2	3	3	5
ODTIONAL ACC	460V CESSORIES - MUST BE ORDERED EX			2		2	3
			0014/04	0014/04	0014/04	0014/04	0014104
Circuit Breaker C		82W01	82W01	82W01	82W01	82W01	82W01
Down-Flow Addit		34J72	44K15	44K15	44K15	44K15	44K15
Down-Flow Conv		83M57	83M57	83M57	83M57	83M57	83M57
Horizontal Suppo		56J18	56J18	56J18	56J18	56J18	56J18
Side Return Unit	, , ,	45K31	45K32	45K32	45K32	45K32	45K32
	er Source Control Box	21H39	21H39	21H39	21H39	21H39	21H39
Step-Down Trans	former Kit (575V applications)			66K90		66K90	66K90
	rcket Kit (Up-Flow)	45K30	45K30	45K30	45K30	45K30	45K30

<sup>&</sup>lt;sup>1</sup> Disposable frame type filter.

<sup>&</sup>lt;sup>3</sup> Blower motor is 460V - 1 phase. Optional electric heat is 460V - 3 phase.

REPLACEMENT C	IRCUIT BREA	KERS					
Voltage	25 amp	30 amp	35 amp	40 amp	45 amp	50 amp	60 amp
208/240V - 1 Phase 2 pole breaker	41K13	17K70	72K07	49K14	17K71	41K12	17K72
208/240V - 3 Phase 3 pole breaker		18M85		41K16	18M86	41K15	41K17

<sup>&</sup>lt;sup>2</sup> HACR type circuit breaker or fuse.

#### **Blower Data**

Externa				Air Vol	ume and Mo	tor Watts at	Specific Blow	er Taps			
Press	sure		High			Medium			Low		
in. w.g.	Pa	cfm	L/s	Watts	cfm	L/s	Watts	cfm	L/s	Watts	
.00	0	1030	485	365	895	425	300	700	330	245	
.05	10	1015	480	360	890	420	295	695	330	245	
.10	25	1000	470	355	875	415	290	690	325	240	
.15	35	980	465	345	860	405	285	680	320	235	
.20	50	960	455	340	845	400	280	665	315	230	
.25	60	935	440	335	825	390	275	650	310	220	
.30	75	910	430	325	800	380	265	635	300	215	
.40	100	850	400	310	745	355	250	590	280	205	
.50	125	780	370	295	685	320	235	535	255	190	
.60	150	705	330	280	605	285	220	470	220	175	
.70	175	615	290	265	520	245	200	395	185	165	
.75	185	565	265	255	475	225	195	350	165	155	

NOTE - All air data is measured external to unit with air filter in place with bottom return air. Electric heaters have no appreciable air resistance.

CBX32M-030	BLOWER P	ERFORMAN	CE (208/230)	v)						
Externa	I Static			Air Vol	ume and Mo	tor Watts at	Specific Blow	er Taps		
Pres	sure		High		Medium			Low		
in. w.g.	Pa	cfm	L/s	Watts	cfm	L/s	Watts	cfm	L/s	Watts
.00	0	1290	610	385	1175	555	335	1045	490	315
.05	10	1295	610	380	1190	560	330	1075	505	310
.10	25	1290	610	375	1190	560	325	1085	515	300
.15	35	1265	600	370	1175	555	320	1085	510	295
.20	50	1230	580	360	1145	540	310	1065	505	285
.25	60	1180	555	350	1105	520	295	1030	485	270
.30	75	1115	525	335	1045	495	280	980	460	255
.40	100	945	445	305	890	420	250	830	390	220
.50	125	720	340	275	675	320	215	615	290	190
.60	150	440	205	240	405	190	185	335	155	160

NOTE - All air data is measured external to unit with air filter in place with bottom return air. Electric heaters have no appreciable air resistance.

External	l Static	Air Volume and Motor Watts at Specific Blower Taps									
Press	sure		High			Medium			Low		
in. w.g.	Pa	cfm	L/s	Watts	cfm	L/s	Watts	cfm	L/s	Watts	
.00	0	1525	720	505	1120	530	390	915	430	335	
.05	10	1520	720	495	1150	540	385	965	455	330	
.10	25	1510	715	480	1170	550	380	1005	475	325	
.15	35	1495	705	470	1180	560	375	1035	490	320	
.20	50	1475	695	455	1190	560	370	1055	495	320	
.25	60	1450	685	440	1185	560	360	1060	500	310	
.30	75	1415	670	430	1175	555	350	1050	495	300	
.40	100	1335	630	400	1135	535	325	1005	475	290	
.50	125	1230	580	375	1060	500	300	915	430	255	
.60	150	1100	520	345	960	455	280	775	365	230	
.70	175	950	450	320	830	390	255	590	280	205	
.75	185	870	410	305	750	355	245	485	230	195	

NOTE - All air data is measured external to unit with air filter in place with bottom return air. Electric heaters have no appreciable air resistance.

External Static		Air Volume & Motor Watt	s at Specific Blower Taps	
Pressure in. w.g.	Hiç	gh	Low	ı
	cfm	Watts	cfm	Watts
0	1525	505	1120	390
0.05	1520	495	1150	385
0.10	1510	480	1170	380
0.15	1495	470	1180	375
0.20	1475	455	1190	370
0.25	1450	440	1185	360
0.30	1415	430	1175	350
0.40	1335	400	1135	325
0.50	1230	375	1060	300
0.60	1100	345	960	280
0.70	950	320	830	255
0.75	870	305	750	245

NOTE - All air data is measured external to unit with air filter in place with bottom return air. Electric heaters have no appreciable air resistance.

External Press				Air Vol	ume and Mo	ime and Motor Watts at Specific Blower Taps					
			High			Medium			Low		
in. w.g.	Pa	cfm	L/s	Watts	cfm	L/s	Watts	cfm	L/s	Watts	
.00	0	1825	860	565	1600	755	455	1325	625	370	
.05	10	1790	845	555	1585	750	455	1335	630	370	
.10	25	1750	825	540	1565	740	450	1335	630	370	
.15	35	1710	805	530	1540	725	440	1330	630	365	
.20	50	1660	785	520	1505	710	435	1320	620	360	
.25	60	1610	760	505	1470	695	425	1300	615	355	
.30	75	1555	735	495	1425	675	415	1270	600	350	
.40	100	1430	675	465	1320	625	390	1195	565	330	
.50	125	1290	610	440	1195	565	365	1090	515	310	
.60	150	1135	535	415	1050	495	335	955	450	285	
.70	175	965	455	385	875	415	310	795	375	260	
.75	185	875	415	370	780	370	295	700	330	250	

NOTE - All air data is measured external to unit with air filter in place with bottom return air. Electric heaters have no appreciable air resistance.

External	Static			Air Vol	ume and Mo	tor Watts at	Specific Blow	er Taps		
Press	sure		High			Medium			Low	
in. w.g.	Pa	cfm	L/s	Watts	cfm	L/s	Watts	cfm	L/s	Watts
.00	0	1910	900	590	1785	845	520	1475	695	430
.05	10	1895	895	585	1770	835	515	1480	700	430
.10	25	1870	880	580	1750	825	510	1475	695	425
.15	35	1840	865	570	1720	810	500	1465	690	420
.20	50	1800	850	565	1685	795	490	1445	680	410
.25	60	1755	830	550	1645	775	480	1415	670	405
.30	75	1700	805	540	1600	755	465	1380	650	395
.40	100	1580	745	515	1485	700	440	1290	610	370
.50	125	1425	675	485	1350	635	410	1170	550	345
.60	150	1250	590	450	1190	560	380	1020	480	320
.70	175	1045	495	415	1000	470	350	840	395	295
.75	185	930	440	400	900	425	335	740	350	280

NOTE - All air data is measured external to unit with air filter in place with bottom return air. Electric heaters have no appreciable air resistance.

External Static		Air Volume & Motor Watts	s at Specific Blower Taps	
Pressure in. w.g.	Hi	gh	Lo	ow
	cfm	Watts	cfm	Watts
0	1870	610	1775	530
0.05	1875	610	1775	530
0.10	1870	590	1765	515
0.15	1850	585	1750	510
0.20	1825	575	1720	500
0.25	1790	560	1685	490
0.30	1745	545	1645	480
0.40	1625	505	1530	450
0.50	1465	470	1380	420
0.60	1270	425	1195	385
0.70	1030	385	975	350
0.75	755	340	720	320

NOTE - All air data is measured external to unit with air filter in place with bottom return air. Electric heaters have no appreciable air resistance.

External				Air Vol	ume and Mot	or Watts at	or Watts at Specific Blower Taps				
Press	sure		High		Medium						
in. w.g.	Pa	cfm	L/s	Watts	cfm	L/s	Watts	cfm	L/s	Watts	
.00	0	2115	995	780	2025	955	670	1775	835	585	
.05	10	2100	990	770	2010	950	665	1775	835	590	
.10	25	2085	985	765	1995	940	655	1770	835	580	
.15	35	2060	970	750	1975	930	645	1760	830	570	
.20	50	2030	960	740	1950	920	635	1745	825	560	
.25	60	2000	945	730	1915	905	625	1725	815	550	
.30	75	1960	925	715	1880	885	610	1695	800	535	
.40	100	1870	880	685	1795	845	580	1630	770	505	
.50	125	1755	830	655	1690	795	545	1540	725	475	
.60	150	1620	765	625	1560	735	515	1425	675	440	
.70	175	1465	690	590	1415	670	480	1295	610	410	
.80	200	1290	610	560	1250	590	445	1140	535	375	
.85	210	1195	565	545	1160	550	425	1050	495	360	

NOTE - All air data is measured external to unit with air filter in place with bottom return air. Electric heaters have no appreciable air resistance.

External Static		Air Volume & Motor Watts	at Specific Blower Taps	
Pressure in. w.g.	Hi	gh	Lo	w
	cfm	Watts	cfm	Watts
0	2140	795	1965	710
0.05	2110	780	1950	700
0.10	2080	765	1930	685
0.15	2045	755	1910	675
0.20	2005	740	1880	660
0.25	1965	725	1850	645
0.30	1920	710	1815	630
0.40	1820	680	1735	600
0.50	1710	650	1635	570
0.60	1585	615	1520	540
0.70	1450	585	1390	505
0.80	1305	550	1245	475
0.85	1225	535	1165	460

NOTE - All air data is measured external to unit with air filter in place with bottom return air. Electric heaters have no appreciable air resistance.

**Parts Arrangements** 




FIGURE 1




FIGURE 2

#### **I-APPLICATION**

CBX32M blower coils are designed for R410A applications only. All major blower coil components must be matched according to Lennox recommendations for the unit to be covered under warranty. Refer to the Engineering Handbook for approved system matchups. A misapplied system will cause erratic operation and can result in early unit failure. The units come with factory installed check and expansion valve for all applications. The TXV valve has been installed internally for a cleaner installation and is accessible if required.

## ELECTROSTATIC DISCHARGE (ESD) Precautions and Procedures

## **A** CAUTION

Electrostatic discharge can affect electronic components. Take precautions during unit installation and service to protect the unit's electronic controls. Precautions will help to avoid control exposure to electrostatic discharge by putting the unit, the control and the technician at the same electrostatic potential. Neutralize electrostatic charge by touching hand and all tools on an unpainted unit surface before performing any service procedure.

#### **II-UNIT COMPONENTS**

#### **A-Control Box**

The CBX32M control box is shown in figure 2. Line voltage and electric heat connections are made in the control box. Optional electric heat fits through an opening located in the center of the control box. When electric heat is not used, knock out plates cover the opening. The electric heat control arrangement is detailed in the electric heat section of this manual.

#### B-Terminal Strip (TB1)

CBX32M units are equipped with a low voltage terminal strip (TB1) located in the control box. See figure 2. The strip is used for making up all indoor thermostat wires. The outdoor unit low voltage wiring connections may be spliced with wire nuts inside the CB units.

#### C-Transformer (T1)

CBX32M series units use a single line voltage to 24VAC transformer mounted in the control box. The transformer supplies power to the control circuits in the indoor and outdoor unit. Transformers on all CBX32M-1 units are rated at 70VA. Transformers on CBX32M-018 through -042-2 units are rated at 70VA and CBX32M-048, -060-2 units are rated at 40VA.

208/240VAC single phase transformers use two primary voltage taps as shown in figure 3.




FIGURE 3

#### D-Circuit Breaker (CB8) -1 units

All transformers used in the CBX32M-1 series units are equipped with internal secondary voltage overcurrent protection. Each transformer uses a circuit breaker (CB8) located on the transformer. The circuit breaker is connected in series with the blue secondary voltage wire and is rated 3.5 Amps.

#### E-Transformer Fuse (F1) -2 units

The transformer in all CBX32M-2 units is protected by an inline fuse (F1). The fuse is rated at 32 volts and 3 amps.

#### F-Blower Relay (K3)

CBX32M units use a DPDT relay to energize the blower motor. The relay coil is energized by blower demand from indoor thermostat. When the coil is energized, a set of N.O. contacts closes to energize the blower motor on cooling speed. When de-energized, a set of N.C. contacts allows the optional electric heat relay to energize the blower on heating speed (refer to unit wiring diagram).

#### **G-Blower Motor (B3)**

CBX32M units use single phase direct drive blower motors with a run capacitor. Figure 4 shows the parts arrangement. All motors use multiple speed taps. Typically, the high speed tap is energized during normal operation. The horse power for each blower motor is listed in table 1.

All units are factory wired for the minimum blower speed for heat pump and cooling applications with or without electric heat. No field wiring is required. The wiring diagrams show factory set blower speeds. To run the blower on high speed, refer to the installation instructions. All speeds shown are minimums. Do not change motor taps to operate at speeds lower than those shown in the tables.




FIGURE 4

#### H-Blower Motor Capacitor (C4)

CBX32M series units use single phase direct drive motors with a run capacitor. The run capacitor is mounted on the blower housing. See figure 4. Capacitor ratings are shown in table 1.

TABLE 1

CBX32M BLOWER RATINGS											
UNIT	HORSE POWER	CAPACITOR RATING									
-018/024	1/5 HP	7.5MFD / 370V									
-030	1/3 HP	15MFD / 370V									
-036	1/3 HP	15MFD / 370V									
-042	1/3HP	20MFD / 370V									
-048	1/3HP	20MFD / 370V									
-060	1/2HP	20MFD / 370V									

#### **I-Coil**

CBX32M series units have dual slab coils arranged in an "A" configuration. Each coil has two or three rows of copper tubes fitted with ripple-edged aluminum fins. An expansion valve complete with screen, feeds multiple parallel circuits through the coils. The coil is designed to easily slide out of the unit cabinet.

#### J-Plastic Drain Pans

Both upflow/downflow and horizontal drain pans are provided and installed on CBX32M units. The drain pans are made from fiberglass filled plastic. The drain hole on horizontal pans are used for right-hand discharge only, and must be plugged when the unit is configured for left-hand discharge.

#### **III-OPTIONAL ECB29 ELECTRIC HEAT**

#### A-Matchups and Ratings

The following tables show all approved CBX32M to ECB29 matchups and electrical ratings.

#### **B-Electric Heat Components**

ECB29 parts arrangement is shown in figures 5 through 9. All electric heat sections consist of components mounted to the electric heat vestibule panel and electric heating elements exposed directly to the air stream. 208/230V electric heat sections may be equipped with circuit breakers. The circuit breakers are designated by CB in the model number. 460 and 575 volt electric heat sections are equipped with fuses. The electric heat section is connected to the unit via jack J2, which plugs into plug P2 of the unit.

# 1-Electric Heat Sequencer Relays (K32, K33, K34, K35, K116, K117) (208/230 volt only)

Relays K32, K33, K34, K35, K116 and K117 are N.O. sequencer relays with a resistive element for a coil and a bi-metal disk which actuates the contacts. The relays are located on the electric heat vestibule panel and are energized by a 24V heating demand (W1, W2, and W3) via jack/ plug 2. When energized, the internal resistance heats the bimetal disk causing the contacts to close. When the relay is de-energized, the disk cools and the contacts open. The relays energize different stages of heat, as well as the blower. The blower is always first on and last off.

#### 2-Primary(S15) & Secondary(S20) Temperature Limits

Both the primary (S15) and secondary (S20) limits are located on the electric heat vestibule panel and are exposed directly to the air stream through an opening in the panel. The high temperature limits are SPST N.C. limits with the primary limit being an auto-reset limit and the secondary limit being a "one-time" limit. One-time limits need to be replaced when opened. The limits are factory set and are not adjustable.

#### 208/230 Volt Electric Heat Sections

Each stage of the 208/230 electric heat is protected by a primary (S15) and secondary (S20) high temperature limit. Both S15 and S20 are located in the same housing. Each stage use the same style of limits. Both the primary and secondary limits are wired in series with a heat element. When either S15 or S20 opens, the corresponding heat element is de-energized. All other heating elements remain energized. The primary high temperature limit opens at  $150^{\circ}F \pm 5^{\circ}F$  (65.5°C  $\pm 2.8^{\circ}C$ ) on a temperature rise and automatically resets at  $110^{\circ}F \pm 9^{\circ}F$  (43.3°C  $\pm 5.0^{\circ}C$ ) on a temperature fall. The secondary high temperature limit opens at  $333^{\circ}F \pm 10^{\circ}F$  (167.2°C  $\pm 5.6^{\circ}C$ ) on a temperature rise. If the secondary limit opens it will need to be replaced.

# 3-Circuit Breaker (CB1, CB2, and CB3) (208/230 volt only)

Line voltage connections are made to circuit breakers CB1, CB2, and CB3 in the electric heat sections with circuit breakers (designated by CB in the model numbers). Table 2 shows the amp rating for each circuit breaker used. Single phase electric heat uses two pole circuit breakers; while three phase electric heat uses three pole circuit breakers.

TABLE 2

ECB29 CIRCUIT BREAKERS											
UNIT	CB1 AMPS	CB2 AMPS	CB3 AMPS								
ECB29-5CB-1 (P)	30 AMP										
ECB29-8CB-1 (P)	50 AMP										
ECB29-10CB-1 (P)	60 AMP										
ECB29-12.5CB-1 (P)	25 AMP	50 AMP									
ECB29-15CB-1 (P)	30 AMP	60 AMP									
ECB29-20CB-1 (P)	60 AMP	60 AMP									
ECB29-25CB-1 (P)	50 AMP	50 AMP	50 AMP								
ECB29-30CB-1 (P)	60 AMP	60 AMP	60 AMP								
ECB29-15CB-1 (Y)	60 AMP										
ECB29-20CB-1 (Y)	40 AMP	35 AMP									
ECB29-25CB-1 (Y)	50 AMP	35 AMP									

Note: Do not remove patch plate or insulation on units without circuit breakers!!

#### 4-Terminal Strip (TB2) 208/230 volt only)

For the electric heat sections without circuit breakers or fuses, line voltage connections are made to terminal strip TB2. The terminal strip is located in the lower left corner of the electric heat vestibule panel. Single phase electric heat uses two pole terminal strips; while three phase electric heat uses three pole terminal strips.

#### 5-Heating Elements (HE1 through HE6)

Heating elements are composed of helix wound bare nichrome wire exposed directly to the air stream. The elements are supported by insulators mounted to the wire frame. For single phase applications, one element is used per stage. Each stage is energized independently by the corresponding relay located on the electric heat vestibule panel. All three phase heating elements are arranged in a three phase delta. Once energized, heat transfer is instantaneous. High temperature protection is provided by primary and secondary high temperature limits.




FIGURE 5




FIGURE 6




FIGURE 7




FIGURE 8




FIGURE 9

ELECTRIC HEAT DAT	TA - CBX32M-018/024							
	Model Number	No. of		Inpu	t	<sup>2</sup> Blower Motor Full	<sup>3</sup> Minimum Circuit	<sup>5</sup> Maximum Overcurrent
		Stages	Volts	kW	<sup>1</sup> Btuh	Load Amps	Ampacity	Protection
SINGLE PHASE						l.		
2.5 kW	ECB29-2.5 (28K30)	1	208	1.9	6,400	1.5	13	15
4 lbs.			220	2.1	7,200	1.5	15	15
			230	2.3	7,800	1.5	15	15
			240	2.5	8,500	1.5	15	15
4 kW	ECB29-4 (55W87)	1	208	3.0	10,250	1.5	20	20
4 lbs.	Terminal Block ECB29-4CB (55W88)		220	3.4	11,450	1.5	23	25
	30A Circuit breaker		230	3.7	12,550	1.5	23	25
			240	4.0	13,650	1.5	23	25
5 kW	ECB29-5 (28K31)	1	208	3.8	12,800	1.5	24	<sup>4</sup> 25
4 lbs.	Terminal Block ECB29-5CB (28K32)		220	4.2	14,300	1.5	28	30
	30A Circuit breaker		230	4.6	15,700	1.5	28	30
			240	5.0	17,100	1.5	28	30
6 kW	ECB29-6 (47L22)	1	208	4.5	15,400	1.5	29	4 30
4 lbs.	Terminal Block ECB29-6CB (47L23)		220	5.0	17,100	1.5	33	35
	35A Circuit breaker		230	5.5	18,800	1.5	33	35
			240	6.0	20,500	1.5	33	35
8 kW	ECB29-8 (28K33)	1	208	6.0	20,500	1.5	38	<sup>4</sup> 40
5 lbs.	Terminal Block ECB29-8CB (28K34)		220	6.7	22,900	1.5	44	45
	45A Circuit breaker		230	7.3	25,100	1.5	44	45
			240	8.0	27,300	1.5	44	45
9 kW	ECB29-9CB (10L11)	2	208	6.8	23,100	1.5	42	<sup>4</sup> 45
5 lbs.	50A Circuit breaker ECB29EH-9CB (91K67)		220	7.6	25,800	1.5	49	50
	50A Circuit breaker		230	8.3	28,200	1.5	49	50
			240	9.0	30,700	1.5	49	50
10 kW	ECB29-10 (28K35)	2	208	7.5	25,600	1.5	47	<sup>4</sup> 50
6 lbs.	Terminal Block ECB29-10CB (28K36)		220	8.4	28,700	1.5	54	60
	60A Circuit breaker		230	9.2	31,400	1.5	54	60
			240	10.0	34,100	1.5	54	60

NOTE - Circuit 1 Minimum Circuit Ampacity includes the Blower Motor Full Load Amps.

1 Electric heater capacity only - does not include additional blower motor heat capacity.

2 Amps shown are for blower motor only.

Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements. Use wires suitable for at least 167°F (75°C).
 Bold text indicates that the circuit breaker on "CB" circuit breaker models must be replaced with size noted. See table on page 2.
 All 575v electric heaters are used with 460v air handler units. A 575v to 460v Step-down transformer for the air handler unit is furnished with all 575v electric heaters.

<sup>&</sup>lt;sup>6</sup> Blower motor is rated at 460V.

<sup>&</sup>lt;sup>7</sup> HACR type circuit breaker or fuse

ELECT	RIC HEAT DATA - CBX32M-030	ı	1			ı	ı		1			
	Model Number	No. of Stages		Inpu	t	<sup>2</sup> Blower Motor Full		imum cuit acity	Overd	cimum current ection		le Point r Source
			Volts	kW	<sup>1</sup> Btuh	Load Amps	Ckt 1	Ckt 2	Ckt 1	Ckt 2	<sup>3</sup> Minimum Circuit Ampacity	<sup>5</sup> Maximum Overcurrent Protection
SINGLE	PHASE											
4 kW	ECB29-4 (55W87)	1	208	3.0	10,250	1.73	20		<sup>4</sup> 20			
4 lbs.	Terminal Block ECB29-4CB (55W88)		220	3.4	11,450	1.73	23		<sup>4</sup> 25			
	30A Circuit breaker		230	3.7	12,550	1.73	23		<sup>4</sup> 25			
			240	4.0	13,650	1.73	23		<sup>4</sup> 25			
5 kW	ECB29-5 (28K31)	1	208	3.8	12,800	1.73	25		<sup>4</sup> 25			
4 lbs.	Terminal Block ECB29-5CB (28K32)		220	4.2	14,300	1.73	28		30			
	30A Circuit breaker		230	4.6	15,700	1.73	28		30			
			240	5.0	17,100	1.73	28		30			
6 kW	ECB29-6 (47L22)	1	208	4.5	15,400	1.73	30		4 30			
4 lbs.	Terminal Block ECB29-6CB (47L23)		220	5.0	17,100	1.73	33		35			
	35A Circuit breaker		230	5.5	18,800	1.73	33		35			
			240	6.0	20,500	1.73	33		35			
8 kW	ECB29-8 (28K33)	1	208	6.0	20,500	1.73	38		<sup>4</sup> 40			
5 lbs.	Terminal Block ECB29-8CB (28K34)		220	6.7	22,900	1.73	44		45			
	45A Circuit breaker		230	7.3	25,100	1.73	44		45			
			240	8.0	27,300	1.73	44		45			
9 kW	ECB29-9CB (10L11)	2	208	6.8	23,100	1.73	43		<sup>4</sup> 45			
5 lbs.	50A Circuit breaker ECB29EH-9CB (91K67)		220	7.6	25,800	1.73	49		50			
	50A Circuit breaker		230	8.3	28,200	1.73	49		50			
			240	9.0	30,700	1.73	49		50			
10 kW	ECB29-10 (28K35)	2	208	7.5	25,600	1.73	47		<sup>4</sup> 50			
6 lbs.	Terminal Block ECB29-10CB (28K36)		220	8.4	28,700	1.73	54		60			
	60A Circuit breaker		230	9.2	31,400	1.73	54		60			
			240	10.0	34,100	1.73	54		60			
12.5 kW	ECB29-12.5CB (28K37)	2	208	9.4	32,000	1.73	21	31	25	<sup>4</sup> 45	60	60
10 lbs.	(1) 25A and (1) 50A Circuit breaker		220	10.5	35,800	1.73	24	35	25	50	61	60
	ECB29EH-12.5CB (91K68)		230	11.5	39,200	1.73	24	35	25	50	61	60
	(1) 25A and (1) 50A Circuit break- er		240	12.5	42,600	1.73	24	35	25	50	67	70
15 kW	ECB29-15CB (28K38)	2	208	11.3	38,400	1.73	24	37	<sup>4</sup> 25	<sup>4</sup> 50	71	80
12 lbs.	(1) 30A and	_	220	12.6	43,000	1.73	28	42	30	60	72	80
	(1) 60A Circuit breaker ECB29EH-15CB (91K69)				,							
	(1) 30A and (1) 60A Circuit break-		230	13.8	47,000	1.73	28	42	30	60	72	80
	er		240	15.0	51,200	1.73	28	42	30	60	80	80

NOTE - Circuit 1 Minimum Circuit Ampacity includes the Blower Motor Full Load Amps.

1 Electric heater capacity only - does not include additional blower motor heat capacity.

2 Amps shown are for blower motor only.

Amps snown are for piower motor only.

3 Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements. Use wires suitable for at least 167°F (75°C).

4 Bold text indicates that the circuit breaker on "CB" circuit breaker models must be replaced with size noted. See table on page 2.

5 All 575v electric heaters are used with 460V air handler units. A 575V to 460V Step-down transformer for the air handler unit is furnished with all 575V electric heaters.

6 Blower motor is rated at 460V.

<sup>&</sup>lt;sup>7</sup> HACR type circuit breaker or fuse

ELECTI	RIC HEAT DATA - CBX32M-036											
	Model Number	No. of Stages		Inpu	t	<sup>2</sup> Blower Motor Full	<sup>3</sup> Min Cir Amp	cuit		kimum current ection	Sing Powe	le Point r Source
			Volts	kW	<sup>1</sup> Btuh	Load Amps	Ckt 1	Ckt 2	Ckt 1	Ckt 2	<sup>3</sup> Minimum Circuit Ampacity	<sup>5</sup> Maximum Overcurrent Protection
SINGLE F	PHASE											
4 kW	ECB29-4 (55W87)	1	208	3.0	10,250	1.72	20		<sup>4</sup> 20			
4 lbs.	Terminal Block ECB29-4CB (55W88)		220	3.4	11,450	1.72	23		<sup>4</sup> 25			
	30A Circuit breaker		230	3.7	12,550	1.72	23		<sup>4</sup> 25			
			240	4.0	13,650	1.72	23		<sup>4</sup> 25			
5 kW	ECB29-5 (28K31)	1	208	3.8	12,800	1.72	25		<sup>4</sup> 25			-
4 lbs.	Terminal Block ECB29-5CB (28K32)		220	4.2	14,300	1.72	28		30			
	30A Circuit breaker		230	4.6	15,700	1.72	28		30			
			240	5.0	17,100	1.72	28		30			
6 kW	ECB29-6 (47L22)	1	208	4.5	15,400	1.72	30		4 30			
4 lbs.	Terminal Block ECB29-6CB (47L23)		220	5.0	17,100	1.72	33		35			
	35A Circuit breaker		230	5.5	18,800	1.72	33		35			
			240	6.0	20,500	1.72	33		35			
8 kW	ECB29-8 (28K33)	1	208	6.0	20,500	1.72	38		<sup>4</sup> 40			
5 lbs.	Terminal Block ECB29-8CB (28K34)		220	6.7	22,900	1.72	44		45			
	45A Circuit breaker		230	7.3	25,100	1.72	44		45			
			240	8.0	27,300	1.72	44		45			
9 kW	ECB29-9CB (10L11)	2	208	6.8	25,600	1.72	43		<sup>4</sup> 45			-
5 lbs.	50A Circuit breaker ECB29EH-9CB (91K67)		220	7.6	28,700	1.72	49		50			
	50A Circuit breaker		230	8.3	31,400	1.72	49		50			
			240	9.0	34,100	1.7	49		50			
10 kW	ECB29-10 (28K35)	2	208	7.5	25,600	1.72	47		<sup>4</sup> 50			
6 lbs.	Terminal Block ECB29-10CB (28K36)		220	8.4	28,700	1.72	54		60			
	60A Circuit breaker		230	9.2	31,400	1.72	54		60			
			240	10.0	34,100	1.72	54		60			
12.5 kW	ECB29-12.5CB (28K37)	2	208	9.4	32,000	1.72	21	31	25	<sup>4</sup> 45	60	60
10 lbs.	(1) 25A & (1) 50A Circuit breaker ECB29EH-12.5CB (91K68)		220	10.5	35,800	1.72	24	35	25	50	61	70
	(1) 25A & (1) 50A Circuit breaker		230	11.5	39,200	1.72	24	35	25	50	61	70
			240	12.5	42,600	1.72	24	35	25	50	67	70
15 kW	ECB29-15CB (28K38)	2	208	11.3	38,400	1.72	24	37	<sup>4</sup> 25	<sup>4</sup> 50	71	80
12 lbs.	(1) 30A & (1) 60A Circuit Breaker ECB29EH-15CB (91K69)		220	12.6	43,000	1.72	28	42	30	60	72	80
	(1) 30A & (1) 60A Circuit Breaker		230	13.8	47,000	1.72	28	42	30	60	72	80
			240	15.0	51,200	1.72	28	42	30	60	80	80
20 kW	ECB29-20CB (11L31)		208	15.0	51,200	1.72	44	41	<sup>4</sup> 45	60	95	100
19 lbs.	(1) 50A & (1) 60A Circuit Breaker ECB29EH-20CB (91K70)		220	16.8	57,300	1.72	49	46	50	60	97	100
	(1) 50A & (1) 60A Circuit Breaker		230	18.4	62,700	1.72	49	46	50	60	97	100
			240	20.0	68,200	1.72	49	46	50	60	106	110
THREE P	PHASE											
8 kW	ECB29-8 (28K42)	1	208	6.0	20,500	1.72	23		25			
5 lbs.	Terminal Block		220	6.7	22,900	1.72	26		30			
			230	7.3	25,100	1.72	26		30			
			240	8.0	27,300	1.72	26		30			
10 kW	ECB29-10 (28K43)	1	208	7.5	25,600	1.72	28		30			
6 lbs.	Terminal Block		220	8.4	28,700	1.72	32		35			
			230	9.2	31,400	1.72	32		35			
			240	10.0	34,100	1.72	32		35			
	ECB29-10 (28K47)	1	440	8.4	28,700	1.1	16		20			
	(3) 20A Fuses		460	9.2	31,400	1.1	16		20			
			480	10.0	34,100	1.1	16		20			

ELECTI	RIC HEAT DATA - CBX32M-036 (Contin	ued										
	Model Number	No. of Stages		Inpu	t	<sup>2</sup> Blower Motor Full	Cir	imum cuit acity		ximum current ection		le Point r Source
			Volts	kW	<sup>1</sup> Btuh	Load Amps	Ckt 1	Ckt 2	Ckt 1	Ckt 2	<sup>3</sup> Minimum Circuit Ampacity	<sup>5</sup> Maximum Overcurrent Protection
THREE P	PHASE											
15 kW	ECB29-15CB (28K44)	1	208	11.3	38,400	1.72	41		<sup>4</sup> 45			
12 lbs.	(1) 50A Circuit breaker		220	12.6	43,000	1.72	47		50			
			230	13.5	47,000	1.72	47		50			
			240	15.0	51,200	1.72	47		50			
	ECB29-15 (28K48)	1	440	12.6	43,000	1.1	24		30			
	(3) 25A Fuses		460	13.8	47,000	1.1	24		30			
			480	15.0	51,200	1.1	24		30			
20 kW	ECB29-20CB (28K45)	2	208	15.0	51,200	1.72	28	21	4 30	4 30	56	60
19 lbs.	(2) 35A Circuit breaker		220	16.8	57,300	1.72	32	24	35	35	58	60
			230	18.4	62,700	1.72	32	24	35	35	58	60
	Circuit 1 Minimum Circuit Annuality includes the		240		68,200	1.72	32	24	35	35	62	70

NOTE - Circuit 1 Minimum Circuit Ampacity includes the Blower Motor Full Load Amps.

<sup>&</sup>lt;sup>6</sup> Blower motor is rated at 460V. <sup>7</sup> HACR type circuit breaker or fuse

ELECTRIC	CHEAT DATA - CBX32M-042											
	Model Number	No. of Stages		Input	İ	<sup>2</sup> Blower Motor Full	<sup>3</sup> Min Cir Amp	cuit	Over	ximum current ection		e Point r Source
			Volts	kW	<sup>1</sup> Btuh	Load Amps	Ckt 1	Ckt 2	Ckt 1	Ckt 2	<sup>3</sup> Minimum Circuit Ampacity	<sup>5</sup> Maximum Overcurrent Protection
SINGLE PH	ASE											
4 kW	ECB29-4 (55W87)	1	208	3.0	10,250	2.4	21		<sup>4</sup> 25			
4 lbs.	Terminal Block ECB29-4CB (55W88)		220	3.4	11,450	2.4	24		<sup>4</sup> 25			
	30A Circuit breaker		230	3.7	12,550	2.4	24		<sup>4</sup> 25			
			240	4.0	13,650	2.4	24		<sup>4</sup> 25			
5 kW	ECB29-5 (28K31)	1	208	3.8	12,800	2.4	26		30			
4 lbs.	Terminal Block ECB29-5CB (28K32)		220	4.2	14,300	2.4	29		30			
	30A Circuit breaker		230	4.6	15,700	2.4	29		30			
			240	5.0	17,100	2.4	29		30			
6 kW	ECB29-6 (47L22)	1	208	4.5	15,400	2.4	30		<sup>4</sup> 30			
4 lbs.	Terminal Block ECB29-6CB (47L23)		220	5.0	17,100	2.4	34		35			
	35A Circuit breaker		230	5.5	18,800	2.4	34		35			
			240	6.0	20,500	2.4	34		35			
8 kW	ECB29-8 (28K33)	1	208	6.0	20,500	2.4	40		<sup>4</sup> 40			
5 lbs.	Terminal Block ECB29-8CB (28K34)		220	6.7	22,900	2.4	45		45			
	45A Circuit breaker		230	7.3	25,100	2.4	45		45			
			240	8.0	27,300	2.4	45		45			
9 kW	ECB29-9CB (10L11)	2	208	6.8	25,600	2.4	44		<sup>4</sup> 45			
5 lbs.	50A Circuit breaker ECB29EH-9CB (91K67)		220	7.6	28,700	2.4	50		50			
	50A Circuit breaker		230	8.3	31,400	2.4	50		50			
			240	9.0	34,100	2.4	50		50			
10 kW	ECB29-10 (28K35)	2	208	7.5	25,600	2.4	48		<sup>4</sup> 50			
6 lbs.	Terminal Block ECB29-10CB (28K36)		220	8.4	28,700	2.4	55		60			
	60A Circuit breaker		230	9.2	31,400	2.4	55		60			
			240	10.0	34,100	2.4	55		60			

Electric heater capacity only - does not include additional blower motor heat capacity.
 Amps shown are for blower motor only.

<sup>&</sup>lt;sup>3</sup> Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements. Use wires suitable for at least 167°F (75°C).

<sup>4</sup> Bold text indicates that the circuit breaker on "CB" circuit breaker models must be replaced with size noted. See table on page 2.

5 All 575v electric heaters are used with 460V air handler units. A 575V to 460V Step-down transformer for the air handler unit is furnished with all 575V electric heaters.

ELECT	RIC HEAT DATA - CBX32M-042 (Contir	nued)										
	Model Number	No. of Stages		Input	t	<sup>2</sup> Blower Motor Full	<sup>3</sup> Min Cir Amp	cuit	Over	ximum current ection		e Point r Source
			Volts	kW	<sup>1</sup> Btuh	Load Amps	Ckt 1	Ckt 2	Ckt 1	Ckt 2	<sup>3</sup> Minimum Circuit Ampacity	<sup>5</sup> Maximum Overcurrent Protection
SINGLE I	PHASE	1										
12.5 kW	ECB29-12.5CB (28K37) (1) 25A & (1) 50A Circuit breaker	2	208	9.4	32,000	2.4	22	31	25	<sup>4</sup> 45	61	70
10 lbs.	ECB29EH-12.5CB (91K68)		220	10.5	35,800	2.4	25	35	25	50	63	70
	(1) 25A & (1) 50A Circuit breaker		230	11.5	39,200	2.4	25	35	25	50	63	70
			240	12.5	42,600	2.4	25	35	25	50	68	70
15 kW	ECB29-15CB (28K38)	2	208	11.3	38,400	2.4	26	37	30	<sup>4</sup> 50	72	80
12 lbs.	(1) 30A & (1) 60A Circuit Breaker ECB29EH-15CB (91K69)		220	12.6	43,000	2.4	29	42	30	60	74	80
	(1) 30A & (1) 60A Circuit Breaker		230	13.8	47,000	2.4	29	42	30	60	74	80
			240	15.0	51,200	2.4	29	42	30	60	81	90
20 kW 19 lbs.	ECB29-20CB (11L31) (1) 50A & (1) 60A Circuit Breaker	2	208	15.0	51,200	2.4	45	41	<sup>4</sup> 45	60	95	100
19 108.	ECB29EH-20CB (91K70)		220	16.8	57,300	2.4	50	46	50	60	99	100
	(1) 50A & (1) 60A Circuit Breaker		230	18.4	62,700	2.4	50	46	50	60	99	100
			240	20.0	68,200	2.4	50	46	50	60	107	110
THREE P	T		000	0.0	00 500	0.4		I	0.5			
8 kW 5 lbs.	ECB29-8 (28K42) Terminal Block	1	208	6.0	20,500	2.4	24		25			
			220	6.7	22,900	2.4	27		30			
			230	7.3	25,100	2.4	27		30			
40 1-14/	EODOO 40 (20K42)	1	240	8.0	27,300	2.4	27		30			
10 kW 6 lbs.	ECB29-10 (28K43) Terminal Block	1	208	7.5	25,600	2.4	29		30			
			220	8.4	28,700	2.4	33		35 35			
			230	9.2	31,400	2.4	33					
	EODOO 40 (20K4Z)	1	240	10.0	34,100	2.4	33		35			
	ECB29-10 (28K47) (3) 20A Fuses	1	440	8.4	28,700							
	. ,		460	9.2	31,400							
15 kW	ECB29-15CB (28K44)	1	480 208	10.0	34,100	2.4	40		4 45			
12 lbs.	(1) 50A Circuit breaker	1	200	11.3 12.6	38,400	2.4	42 48					
			220	12.0	43,000	2.4	40		50			
			230	13.5	47,000	2.4	48		50			
			240	15.0	51,200	2.4	48		50			
	ECB29-15 (28K48)	1	440	12.6	43,000							
	(3) 25À Fuses		460	13.8	47,000							
			480	15.0	51,200							
20 kW	ECB29-20CB (28K45)	2	208	15.0	51,200	2.4	29	21	4 30	4 30	56	60
19 lbs.	(2) 35A Circuit breaker	<del>-</del>	220	16.8	57,300	2.4	33	24	35	35	60	60
			230	18.4	62,700	2.4	33	24	35	35	60	60
			240	20.0	68,200	2.4	33	24	35	35	63	70
ĺ			_ +0	-0.0	30,200		55					. 0

NOTE - Circuit 1 Minimum Circuit Ampacity includes the Blower Motor Full Load Amps.

1 Electric heater capacity only - does not include additional blower motor heat capacity.

2 Amps shown are for blower motor only.

3 Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements. Use wires suitable for at least 167°F (75°C).

4 Bold text indicates that the circuit breaker on "CB" circuit breaker models must be replaced with size noted. See table on page 2.

5 All 575v electric heaters are used with 460V air handler units. A 575V to 460V Step-down transformer for the air handler unit is furnished with all 575V electric heaters.

6 Blower motor is rated at 460V.

7 HACR type circuit breaker or fuse

	Model Number	No. of Stages	Volts Input	kW Input	<sup>1</sup> Btuh Input	<sup>2</sup> Blower Motor Full		Minimu Circuit Ampaci	t	Ov	Maximu ercurre rotectio	ent		le Point r Source
						Load Amps	Ckt 1	Ckt 2	Ckt 3	Ckt 1	Ckt 2	Ckt 3	<sup>3</sup> Minimum Circuit Ampacity	<sup>5</sup> Maximum Overcurren Protection
SINGLE	PHASE									•				
4 kW	ECB29-4 (55W87)	1	208	3.0	10,250	2.4	21			<sup>4</sup> 25				
4 lbs.	Terminal Block ECB29-4CB (55W88)		220	3.4	11,450	2.4	24			<sup>4</sup> 25				
	30A Circuit breaker		230	3.7	12,550	2.4	24			<sup>4</sup> 25				
			240	4.0	13,650	2.4	24			<sup>4</sup> 25				
5 kW	ECB29-5 (28K31)	1	208	3.8	12,800	2.4	26			30				
4 lbs.	Terminal Block ECB29-5CB (28K32)		220	4.2	14,300	2.4	29			30				
	30A Circuit breaker		230	4.6	15,700	2.4	29			30				
			240	5.0	17,100	2.4	29			30				
6 kW	ECB29-6 (47L22)	1	208	4.5	15,400	2.4	30			<sup>4</sup> 30				
4 lbs.	Terminal Block ECB29-6CB (47L23)		220	5.0	17,100	2.4	34			35				
	35A Circuit breaker		230	5.5	18,800	2.4	34			35				
			240	6.0	20,500	2.4	34			35				
3 kW	ECB29-8 (28K33)	1	208	6.0	20,500	2.4	40			4 40				
5 lbs.	Terminal Block		220	6.7	22,900	2.4	45			45				
	ECB29-8CB (28K34) 45A Circuit breaker		230	7.3	25,100	2.4	45			45				
			240	8.0	27,300	2.4	45			45				
) kW	ECB29-9CB (10L11)	2	208	6.8	23,100	2.4	44			<sup>4</sup> 45				
bls.	50A Circuit breaker		220	7.6	25,800	2.4	50			50				
	ECB29EH-9CB (91K67) 50A Circuit breaker		230	8.3	28,200	2.4	50			50				
			240	9.0	30,700	2.4	50			50				
10 kW	ECB29-10 (28K35)	2	208	7.5	25,600	2.4	48			4 50				
6 lbs.	Terminal Block	_	220	8.4	28,700	2.4	55			60				
	ECB29-10CB (28K36) 60A Circuit breaker		230	9.2	31,400	2.4	55			60				
	OUT OF OUR DICARCI		240	10.0	34,100	2.4	55			60				
12.5	ECB29-12.5CB (28K37)	2	208	9.4	32,000	2.4	22	31		25	4 45		61	70
kW	ECB29EH-12.5CB		220	10.5	35,800	2.4	25	35		25	50		63	70
10 lbs.	(91K68) (1) 25A and		230	11.5	39,200	2.4	25	35		25	50		63	70
	(1) 50A Circuit breaker		240	12.5	42,600	2.4	25	35		25	50		68	70
15 kW	ECB29-15CB (28K38)	2	208	11.3	38,400	2.4	26	37		30	4 50		72	80
12 lbs.	ECB29EH-15CB	2	220	12.6	43,000	2.4	29	42		30	60		74	80
	(91K69) (1) 30A and		230	13.5	47,000	2.4	29	42		30	60		74	80
	(1) 60A Circuit breaker				-			1						
20 14V	ECR20 20CB (441 24)	2	240	15.0 15.0	51,200	2.4	29	42		30 4 45	60		81	90
20 kW 19 lbs.	ECB29-20CB (11L31) ECB29EH-20CB	~	208	16.8	51,200 57,300	2.4	45 50	41		50	60 60		95 99	100
	(91K70) (1) 50A and													
	(1) 60A Circuit breaker		230	18.4	62,700	2.4	50	46		50	60		99	100
DE 1/\\	ECD20 25CD (201/42)	2	240	20.0	68,200	2.4	50	46	21	50 4 40	60 4 45	4 45	107	110
25 kW 19 lbs.	ECB29-25CB (28K40) (3) 50A Circuit breakers	3	208	18.8	64,100	2.4	40	31	31				118	125
			220	21.0	71,700	2.4	47	35	35	50	50	50	120	125
			230	23.0	78,300	2.4	47	35	35	50	50	50	120	125
<sup>1</sup> Electr	 - Circuit 1 Minimum Circuit Ampric heater capacity only - does not shown are for blower motor on	ot include					47	35	35	50	50	50	133	150
<ul> <li>Refer</li> <li>Bold</li> <li>All 57</li> <li>Blower</li> </ul>	s shown are for blower motor on to National or Canadian Electri text indicates that the circuit 5v electric heaters are used with er motor is rated at 460V. R type circuit breaker or fuse	ical Code breaker o	n "CB"	circuit	breaker m	odels must	be rep	laced w	ith size	noted.	See tab	le on pa	age 2.	,

	Model Number	No. of Stages		Input		<sup>2</sup> Blower Motor Full	Cir	imum cuit acity		imum urrent ection		le Point r Source
			Volts	kW	<sup>1</sup> Btuh	Load Amps	Ckt 1	Ckt 2	Ckt 1	Ckt 2	<sup>3</sup> Minimum Circuit Ampacity	<sup>5</sup> Maximum Overcurrent Protection
THREE	PHASE		l	1			1	1		I	-	
8 kW	ECB29-8 (28K42)	1	208	6.0	20,500	2.4	24		25			
5 lbs.	Terminal block		220	6.7	22,900	2.4	27		30			
			230	7.3	25,100	2.4	27		30			
			240	8.0	27,300	2.4	27		30			
10 kW	ECB29-10 (28K43)	1	208	7.5	25,600	2.4	29		30			
6 lbs.	Terminal Block		220	8.4	28,700	2.4	33		35			
			230	9.2	31,400	2.4	33		35			
			240	10.0	34,100	2.4	33		35			
	ECB29-10 (28K47)	1	440	8.4	28,700	1.3	17		20			
	(3) 20A Fuses		460	9.2	31,400	1.3	17		20			
			480	10.0	34,100	1.3	17		20			
15 kW	ECB29-15CB (28K44)	1	208	11.3	38,400	2.4	42		<sup>4</sup> 45			
12 lbs.	50A Circuit breaker		220	12.6	43,000	2.4	48		50			
			230	13.5	47,000	2.4	48		50			
			240	15.0	51,200	2.4	48		50			
	ECB29-15 (28K48)	1	440	12.6	43,000	1.3	24		30			
	(3) 25A Fuses		460	13.8	47,000	1.3	24		30			
			480	15.0	51,200	1.3	24		30			
20 kW	ECB29-20CB (28K45)	2	208	15.0	51,200	2.4	29	21	4 30	4 30	56	60
19 lbs.	(2) 35A Circuit breaker		220	16.8	57,300	2.4	33	24	35	35	60	60
			230	18.4	62,700	2.4	33	24	35	35	60	60
			240	20.0	68,200	2.4	33	24	35	35	63	70
	ECB29-20 (28K49)	1	440	16.8	57,300	1.3	32		35			
	(3) 35A Fuses		460	18.4	62,700	1.3	32		35			
			480	20.0	68,200	1.3	32		35			
	<sup>5</sup> ECB29-20 (28K51)	1	550	16.8	57,300	<sup>6</sup> 1.3	26		30			
	(3) 25Å Fuses		575	18.4	62,700	<sup>6</sup> 1.3	26		30			
			600	20.0	68,200	<sup>6</sup> 1.3	26		30			
25 kW	ECB29-25CB (28K46)	2	208	18.8	64,100	2.4	35	27	<sup>4</sup> 40	4 40	70	70
19 lbs.	(2) 45A Circuit breaker		220	21.0	71,700	2.4	41	30	45	45	74	80
			230	23.0	78,300	2.4	41	30	45	45	74	80
			240	25.0	85,300	2.4	41	30	45	45	78	80
	ECB29-25 (28K50)	2	440	21.0	71,700	1.3	39		45			
	(3) 40A Fuses		460	23.0	78,300	1.3	39		45			
			480	25.0	85,300	1.3	39		45			
	<sup>5</sup> ECB29-25 (28K52)	2	550	21.0	71,700	<sup>6</sup> 1.3	32		35			
	(3) 35A Fuses		575	23.0	78,300	<sup>6</sup> 1.3	32		35			
			600	25.0	85,300	<sup>6</sup> 1.3	32		35			

NOTE - Circuit 1 Minimum Circuit Ampacity includes the Blower Motor Full Load Amps.

1 Electric heater capacity only - does not include additional blower motor heat capacity.

2 Amps shown are for blower motor only.

3 Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements. Use wires suitable for at least 167°F (75°C).

4 Bold text indicates that the circuit breaker on "CB" circuit breaker models must be replaced with size noted. See table on page 2.

5 All 575v electric heaters are used with 460V air handler units. A 575V to 460V Step-down transformer for the air handler unit is furnished with all 575V electric heaters.

<sup>&</sup>lt;sup>6</sup> Blower motor is rated at 460V.

<sup>&</sup>lt;sup>7</sup> HACR type circuit breaker or fuse

	Model Number	No. of Stages	Volts Input	kW In- put	<sup>1</sup> Btuh Input	<sup>2</sup> Blower Motor Full		Minimu Circuit Impaci		O۱	Maximu ercurro rotectio	ent		le Point r Source
						Load Amps	Ckt 1	Ckt 2	Ckt 3	Ckt 1	Ckt 2	Ckt 3	<sup>3</sup> Minimum Circuit Ampacity	<sup>5</sup> Maximum Overcurrent Protection
SINGLE	PHASE			U	•		U							
4 kW	ECB29-4 (55W87)	1	208	3.0	10,250	3.9	23			<sup>4</sup> 25				
4 lbs.	Terminal Block		220	3.4	11,450	3.9	26			30				
	ECB29-4CB (55W88) 30A Circuit breaker		230	3.7	12,550	3.9	26			30				
	CONT OFFICIAL DISCARCI		240	4.0	13,650	3.9	26			30				
5 kW	ECB29-5 (28K31)	1	208	3.8	12,800	3.9	27			30				
4 lbs.	Terminal Block		220	4.2	14,300	3.9	31			<sup>4</sup> 35				
	ECB29-5CB (28K32) 30A Circuit breaker		230	4.6	15,700	3.9	31			<sup>4</sup> 35				
	SUA CITCUIL Dreaker		240	5.0	17,100	3.9	31			4 35				
6 kW	ECB29-6 (47L22)	1	208	4.5	15,400	3.9	31			35				
4 lbs.	Terminal Block	'	220	5.0	17,100	3.9	36			4 40				
	ECB29-6CB (47L23)		230	5.5	18,800	3.9	36			4 40				
	35A Circuit breaker		240	6.0	20.500	3.9	36			4 40				
8 kW	ECB29-8 (28K33)	1	208	6.0	20,500	3.9	40			4 40				
5 lbs.	Terminal Block	'	220	6.7	22,900	3.9	47			4 50				
	ECB29-8CB (28K34)		230	7.3		3.9	47			4 50				
	45A Circuit breaker				25,100									
0.1147	E0000 000 (40) 44)		240	8.0	27,300	3.9	47			4 50				
9 kW 5 lbs.	ECB29-9CB (10L11) 50A Circuit breaker	2	208	6.8	23,100	3.9	45			4 45				
J 105.	ECB29EH-9CB (91K67)		220	7.6	25,800	3.9	52			<sup>4</sup> 60				
	50A Circuit breaker		230	8.3	28,200	3.9	52			<sup>4</sup> 60				
			240	9.0	30,700	3.9	52			<sup>4</sup> 60				
10 kW	ECB29-10 (28K35)	2	208	7.5	25,600	3.9	51			60				
6 lbs.	Terminal Block ECB29-10CB (28K36)		220	8.4	28,700	3.9	57			60				
	60A Circuit breaker		230	9.2	31,400	3.9	57			60				
			240	10.0	34,100	3.9	57			60				
12.5	ECB29-12.5CB (28K37)	2	208	9.4	32,000	3.9	23	31		25	<sup>4</sup> 45		63	70
kW	ECB29EH-12.5CB		220	10.5	35,800	3.9	27	35		<sup>4</sup> 30	50		66	70
10 lbs.	(91K68) (1) 25A and		230	11.5	39,200	3.9	27	35		4 30	50		66	70
	(1) 50A Circuit breaker		240	12.5	42,600	3.9	27	35		4 30	50		70	70
15 kW	ECB29-15CB (28K38)	2	208	11.3	38,400	3.9	27	37		30	<sup>4</sup> 50		74	80
12 lbs.	ECB29EH-15CB		220	12.6	43,000	3.9	31	42		<sup>4</sup> 35	60		77	80
	(91K69) (1) 30A and		230	13.5	47,000	3.9	31	42		<sup>4</sup> 35	60		77	80
	(1) 60A Circuit breaker		240	15.0	51,200	3.9	31	42		4 35	60		83	90
20 kW	ECB29-20CB (11L31)	2	208	15.0	51,200	3.9	46	41		50	60		97	100
19 lbs.	ECB29EH-20CB		220	16.8	57,300	3.9	52	46		<sup>4</sup> 60	60		102	110
	(91K70)		230	18.4	62,700	3.9	52	46		<sup>4</sup> 60	60		102	110
	(1) 50A and (1) 60A Circuit breaker		240	20.0	68,200	3.9	52	46		4 60	60		109	110
25 kW	ECB29-25CB (28K40)	3	208	18.8	64,100	3.9	42	31	31	4 45	<sup>4</sup> 45	4 45	120	125
19 lbs.	(3) 50A Circuit breakers		220	21.0	71,700	3.9	48	35	35	50	50	50	122	125
			230	23.0	78,300	3.9	48	35	35	50	50	50	122	125
20 14/4/	ECD20 200D (201/44)	2	240	25.0	85,300	3.9	48	35	35	50	50	50	135	150
30 kW 19 lbs.	ECB29-30CB (28K41) (3) 60A Circuit breakers	3	208	22.5	76,900	3.9	51	37	37	60	<sup>4</sup> 50	<sup>4</sup> 50	144	150
. 0 103.	(5) 557 CHOUNDICARCIS		220	25.2	86,000	3.9	56	42	42	60	60	60	144	150
			230	27.5	94,000	3.9	56	42	42	60	60	60	144	150
			240	30.0	102,40 0	3.9	56	42	42	60	60	60	161	175
	Circuit 1 Minimum Circuit Amr	<del></del>				·								

NOTE - Circuit 1 Minimum Circuit Ampacity includes the Blower Motor Full Load Amps.

1 Electric heater capacity only - does not include additional blower motor heat capacity.

2 Amps shown are for blower motor only.

3 Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements. Use wires suitable for at least 167°F (75°C).

4 Bold text indicates that the circuit breaker on "CB" circuit breaker models must be replaced with size noted. See table on page 2.

5 All 575v electric heaters are used with 460V air handler units. A 575V to 460V Step-down transformer for the air handler unit is furnished with all 575V electric heaters.

6 Blower motor is rated at 460V.

7 HACR type circuit breaker or fuse

Model Number		No. of Stages	Input			<sup>2</sup> Blower Motor Full Load	<sup>3</sup> Minimum Circuit Ampacity		<ul><li><sup>7</sup> Maximum</li><li>Overcurrent</li><li>Protection</li></ul>		Single Point Power Source	
			Volts	kW	<sup>1</sup> Btuh	Amps	Ckt 1	Ckt 2	Ckt 1	Ckt 2	<sup>3</sup> Minimum Circuit Ampacity	<sup>5</sup> Maximum Overcurrent Protection
THREE P					00.500			1			1	
8 kW 5 lbs.	ECB29-8 (28K42) Terminal block	1	208 220	6.0	20,500	3.9	25 29		25			
			230	7.3	22,900 25,100	3.9 3.9	29		30 30			
			240	8.0	27,300	3.9	29		30			
10 kW	ECB29-10 (28K43)	1	208	7.5	25,600	3.9	30		30			
6 lbs.	Terminal Block	•	220	8.4	28,700	3.9	35		35			
			230	9.2	31,400	3.9	35		35			
			240	10.0	34,100	3.9	35		35			
	50000 10 (001/15)				,							
	ECB29-10 (28K47) (3) 20A Fuses	1	440 460	8.4	28,700	1.9	17 17		20 20			
	(0) 20A 1 uses			9.2	31,400	1.9						
			480	10.0	34,100	1.9	17		20			
15 kW 12 lbs.	ECB29-15CB (28K44) 50A Circuit breaker	1	208	11.3	38,400	3.9	43		<sup>4</sup> 45			
			220	12.6	43,000	3.9	50		50			
			230	13.5	47,000	3.9	50		50			
			240	15.0	51,200	3.9	50		50			
	ECB29-15 (28K48)	1	440	12.6	43,000	1.9	25		25			
	(3) 25A Fuses		460	13.8	47,000	1.9	25		25			
			480	15.0	51,200	1.9	25		25			
20 kW	ECB29-20CB (28K45)	2	208	15.0	51,200	3.9	30	21	4 30	<sup>4</sup> 30	58	60
19 lbs.	(2) 35A Circuit breaker		220	16.8	57,300	3.9	35	24	35	35	63	70
			230	18.4	62,700	3.9	35	24	35	35	63	70
			240	20.0	68,200	3.9	35	24	35	35	65	70
Ī	ECB29-20 (28K49) (3) 35A Fuses	1	440	16.8	57,300	1.9	32		35			
			460	18.4	62,700	1.9	32		35			
			480	20.0	68,200	1.9	32		35			
	<sup>5</sup> ECB29-20 (28K51)	1	550	16.8	57,300	<sup>6</sup> 1.9	26		30			
	(3) 25A Fuses		575	18.4	62,700	<sup>6</sup> 1.9	26		30			
			600	20.0	68,200	<sup>6</sup> 1.9	26		30			
25 kW	ECB29-25CB (28K46)	2	208	18.8	64,100	3.9	37	27	4 40	<sup>4</sup> 40	72	80
19 lbs.	(2) 45A Circuit breaker		220	21.0	71,700	3.9	43	30	45	45	77	80
			230	23.0	78,300	3.9	43	30	45	45	77	80
			240	25.0	85,300	3.9	43	30	45	45	80	80
	ECD20 25 (20V50)	2	440		71,700							
	ECB29-25 (28K50) (3) 40A Fuses	2	440	21.0 23.0	71,700	1.9 1.9	40 40		45 45			
	,											
			480	25.0	85,300	1.9	40		45			
	<sup>5</sup> ECB29-25 (28K52) (3) 35A Fuses	2	550	21.0	71,700	<sup>6</sup> 1.9	32		35			
	(3) SOA FUSES		575	23.0	78,300	<sup>6</sup> 1.9	32		35			
	ľ		600	25.0	85,300	<sup>6</sup> 1.9	32		35			

NOTE - Circuit 1 Minimum Circuit Ampacity includes the Blower Motor Full Load Amps.

1 Electric heater capacity only - does not include additional blower motor heat capacity.

<sup>&</sup>lt;sup>2</sup> Amps shown are for blower motor only.

<sup>&</sup>lt;sup>3</sup> Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements. Use wires suitable for at least 167°F (75°C).

<sup>4</sup> Bold text indicates that the circuit breaker on "CB" circuit breaker models must be replaced with size noted. See table on page 6.

5 All 575v electric heaters are used with 460V air handler units. A 575V to 460V Step-down transformer for the air handler unit is furnished with all 575V electric heaters.

<sup>&</sup>lt;sup>6</sup> Blower motor is rated at 460V.

<sup>&</sup>lt;sup>7</sup> HACR type circuit breaker or fuse

#### **IV-CONFIGURATION MODIFICATIONS**

CBX32M units may be installed in the upflow, downflow, horizontal right-hand discharge or horizontal left-hand discharge orientation.

The units come from the factory ready for upflow or horizontal right-hand discharge installation. If the unit needs to be modified from its original configuration, use the following procedures. All procedures assume the unit has not been modified from the factory.

#### A-Disassembly of CBX32M Cabinet

For tight applications where a modular design is an advantage, the CBX32M unit can be easily disassembled and reassembled. By removing four screws, the coil lifts off so the unit is in two parts. To disassemble the CBX32M, use the following procedure.

- 1- Remove the two black screws located just above the seam in the top half of the unit.
- 2- Remove the front access panel and remove the two screws on the inside of the top half of the cabinet on both sides.
- 3- Lift the top section apart from the bottom section.
- 4- To lighten the cabinet for lifting, the blower and coil assemblies can also be removed.
- 5- Reassemble once the cabinet is in place.

#### **B-Upflow Application**

- 1- Discard drip shields, if applicable. The shields are used for downflow applications only and are located with the foam pads on top of new units.
- 2- For best efficiency and air flow, the horizontal drain pan should be removed from units in upflow configurations.
- 3- After removing horizontal drain pan, place unit in desired location. Set unit so that it is level. Connect return and supply air plenums as required using sheet metal screws. See figure 10.




FIGURE 10

#### **C-Downflow Application**

NOTE -CBX32M-018/024 units do not require downflow drip shields.

The following tables outline the sizes of the various drip shields.

TABLE 3
Downflow Drip Shields

CBX32M Unit	Part No.	Length	Width
-030	LB-88658	15.75	2.9187
-036, -042	LB-88663	17.75	3.9187
-048, -060	LB-88664	19.75	3.9187

- 1 Remove the access panels. If necessary, remove the corrugated padding between the blower and coil assembly before operating the unit. Remove the drip shields from the foam pads on the top of the unit.
- 2 Remove the coil assembly from the unit.
- 3 For best efficiency and air flow, remove the horizontal drain pan from the units in downflow positions. See figure 11.
- 4 Rotate cabinet 180° from the upright position. See figure
   11. You may need to first remove the blower assembly to lighten the cabinet for lifting.




FIGURE 11




FIGURE 12

- 5 From the underside of the coil, install the downflow drip shield firmly in place. See figure 12.
- 6 Replace the coil assembly and blower if you have removed it. Replace the coil access panel. See figure 11.
- 7 -Set the unit so that it is level. Connect the return and supply air plenums as required using sheet metal screws.

NOTE - For downflow application, you must use metal or class I supply and return air plenums.

NOTE-For downflow application, metal or class I supply and return air plenums must be used.

For downflow installation on combustible flooring, an additive base must be used. See figure 13.




FIGURE 13




FIGURE 14

Cut an opening appropriately sized for combustible base. Base dimensions are shown in figure 14. After opening has been cut, set the additive base into opening. Connect outlet air plenum to the additive base. Set the unit on the additive base so flanges of the unit drop into the base opening and seal against the insulation

strips. Seal around the insulation strips with permagum. The unit is now locked in place. Install return air plenum and secure with sheet metal screws.

# D-Horizontal Right-Hand Discharge Application

- 1- Discard drip shields, if applicable. The shields are used for downflow applications only.
- 2- Place blower coil on its right side.
- 3- No further adjustment is necessary. Set unit so it is sloped towards the drain pan (1/4" [6mm]). See figure 15.

NOTE-For horizontal applications, a secondary drain pan is recommended. Refer to local codes.

NOTE-For horizontal applications in **high humidity areas**, remove the downflow rail closest to the drain pan. To remove rail, remove screw from rail at back of unit and at cabinet support rail. Remove downflow rail then replace screws. Also, seal around the exiting drain pipe, liquid and suction lines to prevent infiltration of humid air.




FIGURE 15

3- If hanging the unit, it must be supported along the entire length of the cabinet. If using chain or strap, use a piece of angle iron or sheet metal attached to the unit (either above or below) so that the full length of the cabinet is supported. Use securing screws no longer than 1/2" (13mm) to avoid damage to coil or filter. See figure 16. Connect return and supply air plenums as required using sheet metal screws.




FIGURE 16

## **A** CAUTION

Danger of equipment damage and personal injury. Take care when removing coil assembly from unit installed in right or left-hand applications. Coil may tip into drain pan once clear of cabinet. Support coil when removing.

#### E-Horizontal Left-Hand Discharge Application

NOTE-For horizontal applications, a secondary drain pan is recommended. Refer to local codes.

- 1- Discard drip shields, if applicable. The shields are used for downflow applications only.
- 2- Pull coil assembly from unit. Pull off the horizontal drain pan.
- 3- Remove drain plugs from back drain holes on horizontal drain pan and re-install them on front holes.
- 4- Rotate drain pan 180° front to back and install it on the opposite side of coil.
- 5- Remove screws from top cap. Remove horizontal drip shield screw located in the center of the back coil end seal. See figure 17.
- 6- Rotate horizontal drip shield 180° front to back.
- 7- Remove plastic plug from left hole on coil front end seal and re-install plug in back hole. Re-install horizontal drip shield screw in front coil end seal. Drip shield should drain downward into horizontal drain pan inside coil.
- 8- Rotate top cap 180° front to back and align with unused screw holes. Holes must align with front and back coil end plates. Note that top cap has a 45° bend on one side and 90° bend on the other. The 90° bend must be on the same side as the horizontal drain pan. See figures 17 and 18.

NOTE-Use extreme care when re-installing screws into coil end plate engaging holes. Coil damage could result by misalignment.




FIGURE 17




FIGURE 18

9- From the upflow position, replace coil assembly. Then flip cabinet 90° to the left and set into place. Replace coil assembly. Secure coil in place by bending down tab on cabinet support rail. See figures 17 and 19.





FIGURE 19

NOTE-For horizontal applications in **high humidity areas**, remove the downflow rail closest to the drain pan. To remove rail, remove screw from rail at back of unit and at cabinet support rail. Remove downflow rail then replace screws. Also, seal around the exiting drain pipe, liquid and suction lines to prevent infiltration of humid air.

- 11- Flip access door. Knock out the portion of door for the drain pipes and attach to the cabinet with screw provided. Replace access door on the unit.
- 12- Set unit so it is sloped towards the drain pan (1/4" [6mm]). Connect return and supply air plenums as required using sheet metal screws.
- 13- If hanging the unit, it must be supported along the entire length of the cabinet. If using chain or strap, use a piece of angle iron or sheet metal attached to the unit (either above or below) so that the full length of the cabinet is supported. Use securing screws no longer than 1/2" (13mm) to avoid damage to coil or filter. See figure 16. Connect return and supply air plenums as required using sheet metal screws.


#### F-Condensate Drain

A 5" (127mm) section of PVC pipe is provided with the unit. Cut the pipe in half and use to route the auxiliary and main drains. Connect main condensate drain and route downward to an open drain or sump. Do not connect drain to a closed waste system. Refer to figure 20 for typical condensate trap configuration.



#### FIGURE 20

It is recommended that the auxiliary drain be connected to a drain line for all units. If auxiliary drain is not connected, it must be plugged with provided cap. For downflow units, the auxiliary drain MUST be connected and routed to a drain. See figure 21 for auxiliary and main drain locations.



The following practices are recommended to ensure condensate removal:

- Drain piping should not be smaller than the drain connections at drain pan.
- 2- A trap must be installed in the main drain line.

- 3- The trap must be deep enough to offset the difference in static pressure between drain pan and atmosphere. Generally, two inches is satisfactory for medium static applications.
- 4- Horizontal runs must be sloped 1" (25mm) per 10 feet (3.1m) of drain line to offset friction.
- 5- An open vent in drain line will sometimes be required due to line length, friction and static pressure.
- 6- Drains should be constructed in a manner to facilitate future cleaning and not to interfere with filter access. See figure 20.
- 7- Auxiliary drain should run to an area where homeowner will notice it draining. Refer to local codes.

#### **V-START-UP - OPERATION**

#### A-Preliminary and Seasonal Checks

- Make sure the unit is installed in accordance with the installation instructions.
- 2- Inspect electrical wiring, both field and factory installed for loose connections. Tighten as required.
- 3- Check voltage at disconnect switch. Voltage must be within range listed on the nameplate. If not, consult the power company and have voltage condition corrected before starting unit.

- 4- Check to ensure that refrigerant lines are in good condition and pipe insulation is intact.
- 5- Inspect condition of condensate drain pan and piping assembly. Disassemble and clean seasonally.

#### **B-Cooling Start-Up**

NOTE-The following is a generalized procedure and does not apply to all thermostat control systems. Electronic thermostat control systems may operate differently.

- 1- Set fan switch to AUTO or ON and move the system selection switch to COOL. Adjust the thermostat to a setting far enough below room temperature to bring on the compressor. Compressor will start and cycle on demand from the thermostat.
- 2- The refrigerant circuit is charged with R410A refrigerant. See condensing unit rating plate for correct charge amount.
- Refer to the correct condensing unit service manual for more information.

#### **C-Heating Start-Up**

- 1- Set the fan switch to AUTO or ON and move the system selection switch to HEAT. Adjust the thermostat setting above room temperature.
- 2- The indoor blower immediately starts and the electric heat will stage on based on sequencer timing.

#### **D-Safety or Emergency Shutdown**

Turn off unit power at circuit breaker.

#### **E-Extended Period Shutdown**

Turn off thermostat or set to "UNOCCUPIED" mode. Turn off power to unit. All access panels and covers must be in place and secured.

The condensate assembly should be clean and dry for extended period shutdown.

# VI-TYPICAL OPERATING CHARACTERISTICS A-Blower Operation and Adjustment

NOTE- The following is a generalized procedure and does not apply to all thermostat controls.

- 1- Blower operation is dependent on thermostat control system.
- 2- Generally, blower operation is set at thermostat subbase fan switch. With fan switch in ON position, blower operates continuously. With fan switch in AUTO position, blower cycles with demand.
- 3- In all cases, blower and entire unit will be off when the system switch is in OFF position.

#### **B-External Static Pressure**

1- Measure tap locations as shown in figure 22.




FIGURE 22

- 2- Punch a 1/4" (6mm) diameter hole in supply and return air plenums. Insert manometer hose flush with inside edge of hole or insulation. Seal around the hose with permagum. Connect the zero end of the manometer to the discharge (supply) side of the system. On ducted systems, connect the other end of manometer to the return duct as above. For systems with non-ducted returns, leave the other end of the manometer open to the atmosphere.
- 3- With only the blower motor running and the evaporator coil dry, observe the manometer reading. Adjust blower motor speed to deliver the air desired according to the job requirements.
- External static pressure drop must not exceed 0.5"
   W.C. (1.2 kPa)
- 5- Seal around the hole when the check is complete.

#### C-Blower Speed Taps

Blower speed tap selection is accomplished by changing the taps at the blower motor harness connector. Disconnect harness connector from motor to expose speed selectors. Blower speed selections are listed on the wiring diagrams. Refer to the ECB29 installation instructions for minimum allowable blower speed, when using electric heat.

#### To Change Blower Speed

- 1- Turn off electric power to furnace.
- 2- Remove blower access door.
- 3- Disconnect blower motor harness from motor.
- 4- Select desired speeds for heating and cooling. (Black = cooling high speed, Orange = common, Yellow = electric heat only).
- 5- Depress harness connector tab to release wire terminal. Select connector location for new speed (refer to unit wiring diagram). Insert wire terminal until it is securely in place. See figure 23.
- 6- Replace harness connector to motor.




FIGURE 23

#### **VII-MAINTENANCE**

At the beginning of each heating/cooling season, the system should be checked as follows:

#### **A-Filters**

NOTE- Filter access panel must be in place during unit operation. Excessive warm air entering the unit may result in water blow-off problems.

**TABLE 4** 

CBX32M FILTER SIZES					
Unit	Filter Size				
CBX32M-018/024	15" X 20" (381mm X 508mm)				
CBX32M-030, -036, -042	20" X 20" (508mm X 508mm)				
CBX32M-048, -060	20" X 24" (508mm X 610mm)				


To remove filter, loosen the thumbscrews holding the filter panel in place. Slide filter out of the guides on either side of cabinet, insert new filter and replace panel. Some models come with a spacer so standard size filters can be used. Filters should be inspected monthly and must be replaced when dirty to ensure proper blower coil operation. See table 4 for replacement filter sizes or see the sticker located on the filter access door specifying the size of the standard throw-away filter which is used with the unit.

#### **B-Supply Air Blower**

- 1- Check and clean blower wheel.
- 2- Motors are prelubricated for extended life; no further lubrication is required.

#### **C-Electrical**

- 1- Check all wiring for loose connections.
- 2- Check circuit breaker located in unit control box.
- 3- Check for correct voltage at unit (unit operating).
- 4- Check amp-draw on blower motor.
- 5- Check to see that heat (if applicable) is operating.



#### A-CBX32M - 208/230V SINGLE-PHASE - SEQUENCE OF OPERATION

- Line voltage is routed to transformer T1 and blower motor B3.
- 2- T1 supplies 24VAC to terminal strip TB1, which supplies 24VAC to the indoor thermostat and electric heat, if used.


#### **HEATING**


- 3- When there is a call for heat, W1 of the thermostat energizes the electric heat relay K32 (covered in the electric heat section).
- 4- Blower motor B3 is energized on heating speed after K32-1 closes (see electric heat).

- 5- Economizer relay K43 (if used) is energized after K32-1 closes (see electric heat section).
- 6- K43-1 closes energizing the economizer with 24VAC.

#### **COOLING**


- 7- When there is a call for cooling, G of the thermostat energizes blower relay K3 and the economizer, if used.
- 8- K3-2 closes energizing blower motor B3 on cooling speed.






#### B-ECB29-2.5, -5, -5CB, -8, -8CB - 208/230V SINGLE-PHASE - SEQUENCE OF OPERATION

- 1- When there is a call for heat, W1 of the thermostat energizes the electric heat relay K32 with 24VAC.
- 2- When K32-1 closes, the blower is energized on heating speed and economizer heat relay K43 is energized (see 208/230VAC CB schematic).
- 3- Assuming the N.C. primary (S15) and secondary (S20) limit switches are closed, electric heat element HE1 is energized.
- 4- When K32-2 closes, assuming the N.C. primary (S15) and secondary (S20) limit switches are closed, electric heat element HE2 is energized.




#### C-ECB29-2.5, -5, -5CB, 208/230V SINGLE-PHASE - SEQUENCE OF OPERATION

- 1- When there is a call for heat, W1 of the thermostat energizes the electric heat relay K32 with 24VAC.
- 2- When K32-1 closes, the blower is energized on heating speed and economizer heat relay K43 is energized (see 208/230VAC CB schematic).
- 3- When K32-2 closes, assuming N.C. primary (S15) and the secondary (S20) limit switches are closed, electric heat element HE1 is energized.




# D-ECB29-10, -10CB - 208/230V SINGLE-PHASE - SEQUENCE OF OPERATION FIRST STAGE HEAT SECOND STAGE HEAT

- 1- When there is a call for heat, W1 of the thermostat energizes the electric heat relay K32 with 24VAC.
- 2- When K32-1 closes, the blower is energized on heating speed and economizer heat relay K43 is energized (see 208/230VAC CB schematic).
- 3- K32-3 closes and assuming the N.C. primary (S15) and secondary (S20) limit switches are closed, electric heat element HE1 is energized.
- SECOND STAGE HEAT (remove jumper between W2 and R)
  - 4- When K32-2 closes, the unit is ready for a second stage heat demand. W2 of the thermostat sends a second stage heat demand, energizing the electric heat relay K33 with 24VAC.
- 5- When K33-2 closes, assuming the N.C. primary (S15) and secondary (S20) limit switches are closed, electric heat element HE2 is energized. K33-1 closes until second sage heat demand is satisfied.



# E-ECB29-12.5CB, -15CB - 208/230V SINGLE-PHASE - SEQUENCE OF OPERATION FIRST STAGE HEAT SECOND STAGE HEAT (remove jumper between W2 and R)

- 1- When there is a call for heat, W1 of the thermostat energizes electric heat relays K32 and K33 with 24VAC.
- 2- When K32-1 closes, the blower is energized on heating speed and economizer heat relay K43 is energized (see 208/230VAC CB schematic).
- 3- When K32-2 closes, assuming the N.C. primary (S15) and secondary (S20) limit switches are closed, electric heat element HE2 is energized.
- 4- When K33-1 closes, the unit is ready for a second stage heat demand. When K33-2 closes, assuming the N.C. primary (S15) and secondary (S20) limit switches are closed, electric heat element HE1 is energized.
- 5- W2 of the thermostat sends a second stage heat demand, energizing electric heat relay K34 with 24VAC.
- 6- When K34-1 closes, assuming the N.C. primary (S15) and secondary (S20) limit switches are closed, heating element HE3 is energized. K34-1 closes until second stage demand is satisfied.



## F-ECB29-20CB - 208/230V SINGLE-PHASE - SEQUENCE OF OPERATION


#### FIRST STAGE HEAT

- 1- When there is a call for heat, W1 of the thermostat energizes electric heat relays K32 and K33 with 24VAC.
- 2- When K32-1 closes, the blower is energized on heating speed and economizer heat relay K43 is energized (see 208/230VAC CB schematic).
- 3- When K32-2 closes, assuming the N.C. primary (S15) and secondary (S20) limit switches are closed, electric heat element HE3 is energized.
- 4- When K33-2 closes, assuming the N.C. primary (S15) and secondary (S20) limit switches are closed, electric heat element HE4 is energized.

#### SECOND STAGE HEAT

#### (remove jumper between W2 and R)

- 5- When K33-1 closes, the unit is ready for a second stage heat demand. W2 of the thermostat sends a second stage heat demand, energizing the electric heat relays K34 and K35 with 24VAC.
- 6- When K34-2 closes, assuming the N.C. primary (S15) and secondary (S20) limit switches are closed, heating element HE2 is energized. K34-1 closes until second stage heat demand is satisfied.
- 7- When K35-1 closes, assuming the N.C. primary (S15) and secondary (S20) limit switches are closed, electric heat element HE1 is energized.



### G-ECB29-25CB, -30CB - 208/230V SINGLE-PHASE - SEQUENCE OF OPERATION

#### FIRST STAGE HEAT

- 1- When there is a call for heat, W1 of the thermostat energizes the electric heat relays K32 and K34 with 24VAC.
- 2- When K32-1 closes, the blower is energized on heating speed and economizer heat relay K43 is energized (see 208/230VAC CB schematic).
- 3- When K32-2 closes, assuming the N.C. primary (S15) and secondary (S20) limit switches are closed, electric heat element HE1 is energized.
- 4- When K34-2 closes, assuming the N.C. primary (S15) and secondary (S20) limit switches are closed, electric heat element HE2 is energized.

#### SECOND STAGE HEAT

#### (remove jumper between W2 and R)


5- When K34-1 closes, the unit is ready for a second stage heat demand. W2 of the thermostat sends a second stage heat demand, energizing the electric heat relays K33 and K116 with 24VAC.

- 6- When K33-2 and K16-1close, assuming primary (S15) and secondary (S20) limit switches are closed, electric heat elements HE3 and HE6 are energized.
- 7- K33-1 closes and remains closed until second stage heat demand is satisfied.

#### THIRD STAGE HEAT

#### (remove jumper between W3 and R, if using third stage)

- 8- When K32-3 closes, the unit is ready for a third stage heat demand. W3, if available, of the thermostat sends a third stage heat demand, energizing the electric heat relays K35 and K117 with 24VAC.
- 9- When K35-2 and K117-1 close, assuming the N.C. primary (S15) and secondary (S20) limit switches are closed, electric heat elements HE4 and HE5 are energized. K35-1 closes until third stage heat demand is satisfied.




#### H-ECB29-5, -8, -10, -15CB - 208/230V THREE-PHASE - SEQUENCE OF OPERATION

- 1- When there is a call for heat, W1 of the thermostat energizes the electric heat relays K32, K33 and K34 with 24VAC.
- 2- When K32-1 and/or K33-1 closes, the blower is energized on heating speed and economizer heat relay K43 is energized

(see 208/230VAC CB schematic).

3- When K32-2, K33-2 and K34-1 closes, assuming the N.C. primary (S15) and secondary (S20) limit switches are closed, electric heat elements HE1, HE2, and HE3 are energized.



# I-ECB29-20CB, -25CB - 208/230V THREE-PHASE - SEQUENCE OF OPERATION heat demand, energizing the electric features and the second of the second

- 1- When there is a call for heat, W1 of the thermostat energizes the electric heat relays K32 and K34 with
- 2- When K32-1 closes, the blower is energized on heating speed and economizer heat relay K43 is energized (see 208/230VAC CB schematic).
- 3- When K32-1 and K32-2 closes, assuming the N.C. primary (S15) and secondary (S20) limit switches are closed, electric heat elements HE1 and HE2 are energized.
- 4- When K34-1 closes, assuming the N.C. primary (S15) and secondary (S20) limit switches are closed, electric heat element HE3 is energized.

#### SECOND STAGE HEAT

#### (remove jumper between W2 and R)

5- When K34-2 closes, the unit is ready for a second stage heat demand. W2 of the thermostat sends a second stage

- heat demand, energizing the electric heat relays K33 and K35 with 24VAC.
- 6- When K33-1 closes, the blower (if not energized) is energized on heating speed and economizer heat relay K43 is energized (see 208/230VAC CB schematic).
- 7- When K33-1, K35-1, and K35-2 contacts close, assuming the N.C. primary (S15) and secondary (S20) limit switches are closed, electric heat elements HE4, HE5, and HE6 are energized.