

White
Rodgers™



EMERSON®
BLUE™ Wireless Comfort Interface
1F98EZ-1621
HOMEOWNER USER GUIDE





EMERSON™
Climate Technologies

Message to Homeowners

Congratulations on choosing the Emerson Blue Wireless Control System! This system features an intuitive **Comfort Interface** that utilizes wireless technology for precise and reliable temperature control found in all Emerson products.

The Emerson Blue Wireless Control System consists of a **Comfort Interface**, **Equipment Control Module**, **Return Air Sensor** and optional **Indoor/Outdoor Remote Sensors** (F145RF-1600). The **Comfort Interface** provides a large, uncluttered display for adjustments to your home's temperature, humidity, and system configuration. Powered with batteries, it communicates wirelessly to the **Equipment Control Module** and **Return Air Sensor** (located near your furnace and air handler). For added performance, this system can be configured to work with up to 3 indoor and 1 outdoor **Remote Sensor(s)** (sold separately).

When "Change " appears in the display, a new set of premium brand AA alkaline batteries should be installed. If the house will be unoccupied for an extended period, it is recommended that new batteries be installed before leaving.


Need Help? For assistance with this product, please call 800-284-2925.

Table of Contents


	Page		Page
Overview	3	Temporary Program Override	17
Quick Start Guide	6	Permanent Temperature Hold	17
Set Current Time and Day	6	Auxiliary Heating	18
Energy Saving Pre-Program	8	Dual Fuel Setpoint	18
Programming Your Comfort Interface	9	Averaging with Indoor Remote Sensor...18	
Planning Your Program	9	System Diagnostics	18
Programming Tips – Copy Program.....	9	Humidification and Dehumidification	
Heating and Cooling Worksheets	10	Control	18
Enter Heating Program	11	Humidity and Outdoor Temperature	
Enter A/C Program	15	Display	19
Using Your Comfort Interface	16	Replacing Batteries	20
Operating Your System	16	Configuration Menu Options	23
Operating Your Fan	16	Homeowner Help Line	28

Overview

Comfort Interface Display




Other Display Icons



Overview

1. **"Heat"**, **"A/C"**, **"Fan"**, and **"Off"** button labels. When filled, indicates system mode selected.
2. **"Connect"**, **"Time"**, **"Schedule"**, and **"Next Day"** additional button labels in additional display modes.
3. **"Aux"** indicates configured for Heat Pump. **"Aux"** indicates Auxiliary (Emergency) stage selected.
4. **"Auto"** indicates auto changeover mode can be selected. **"Auto"** indicates System is in Auto changeover mode.
5. **"Run"** identifies button to begin running the program, **"Hold"** identifies button to press to hold temperature.
6. **"Menu"** identifies button to press for menus. **"Copy"** identifies button to copy program in Schedule mode.
7. **"°C"** indicates temperature displayed in Celsius.
8. **"Limit"** indicates temperature is adjusted to the limit set in the configuration menu.
9. **"Set"** indicates desired temperature.
10. **"Temp Hold"** indicates temperature is changed for temporary length of time and will return to program temperature, **"Hold"** indicates temperature will be maintained until **"Run"** is pressed.


Overview

11.  indicates that Comfort Interface is in either partial or full keypad lock.
12. Indicates program period, **"Morn"** **"Day"** **"Eve"** or **"Night"**.
13. **"Wireless Setup"** appears when in the wireless set up mode.
14. **"Humidity"** indicates Humidity is being displayed instead of current time.
15. **"Outdoor"** indicates display is showing outdoor temperature (if outdoor sensor is installed) instead of time.
16. Indicates afternoon (PM). No indication for Morning (AM).
17. **"%"** display is showing Humidity setting instead of Time of Day.
18. **"Month"** **"Year"** **"Date"** displays when setting time and date.
19. **"Call for Service"** displays when a fault occurs in the system.
20. **"Change Filter"** **"Change Pad"** displays if filter timer or humidifier timer is set and time has expired.
21. **"Searching"** in Wireless Setup appears when searching for components, **"Connected"** displays to show connected to wireless component or **"Failed"** appears to indicate loss of communication.
22. **Dehumidification/Humidification** indicator.


Quick Start Guide

Set Current Time and Day

1. On the Home screen, press **Menu** button to display additional selections.




2. Press the **Time** button to display hour and "**A**" (AM) or "**P**" (PM) in the clock display.








Quick Start Guide

3. Press the  or  button to adjust the hour and "A" (AM) or "P" (PM).



4. Press **Time** to display the minutes.



5. Press the  or  button to adjust the minutes.
6. Press **Time** to display the year, month, and day of week.
7. Press the  or  button to adjust.
8. Press **Run** to return to home screen.

Quick Start Guide

Energy Saving Pre-Program

This Comfort Interface is set up for 7 independent day programming with 4 time/temperature periods per day. If the factory programming meets your needs, skip to the **"Using Your Comfort Interface"** section, page 15. If you wish to change the heating or A/C schedules, please proceed to the **"Programming Your Comfort Interface"** section on next page.

Factory Pre-Programmed schedule for four periods per day, all days of the week

	Wake Up (Morning)		Leave For Work (Day)		Return Home (Evening)		Go To Bed (Night)	
Heating Program	6:00 AM	70°F	8:00 AM	62°F	5:00 PM	70°F	10:00 PM	62°F
A/C Program	6:00 AM	75°F	8:00 AM	83°F	5:00 PM	75°F	10:00 PM	78°F

Factory Pre-Programmed schedule for two period Day / Night programs

	Day		Night	
Heating Program	6:00 AM	70°F	10:00 PM	62°F
A/C Program	6:00 AM	75°F	10:00 PM	78°F

If you prefer your Comfort Interface to be non-programmable, refer to the **"Configuration Menu Options"**, menu # 03, page 20.

Programming Your Comfort Interface ---

Planning Your Program

The Worksheet on page 10 allows you to pencil in your own program times and temperatures. Factory settings are listed on Monday (for Monday thru Friday), Saturday and Sunday.

If you are re-programming all 7 days, fill in all lines with the times and temperatures you want. Use this worksheet as a guide to reprogram the Comfort Interface. Keep the following guidelines in mind when planning your program.

- > In Heating, lower temperatures will save energy.
- > In A/C, higher temperatures will save energy.

Programming Tips - Copy Program

When programming your Comfort Interface, you may copy the program from one day to another day. To copy a program:

1. In **Schedule** mode, enter the program for the day.
2. Press **Copy**. The copied day will be solid and the flashing day(s) identifies where the copied program will be saved.
3. Press **Next Day** to change the day(s) where the copied program will be saved.
4. Press **Copy**. The program is now copied to the new day(s).

Programming Your Comfort Interface ---

Fill in the blank worksheet with your desired times and temperatures:

Worksheet for Re-Programming 7-Day Program


Heating Program	Wake Up (Morning)		Leave For Work (Day)		Return Home (Evening)		Go To Bed (Night)	
MON	6:00 AM	70°F	8:00 AM	62°F	5:00 PM	70°F	10:00 PM	62°F
TUE								
WED								
THU								
FRI								
SAT	6:00 AM	70°F	8:00 AM	70°F	5:00 PM	70°F	10:00 PM	62°F
SUN	6:00 AM	70°F	8:00 AM	70°F	5:00 PM	70°F	10:00 PM	62°F

A/C Program	Wake Up (Morning)		Leave For Work (Day)		Return Home (Evening)		Go To Bed (Night)	
MON	6:00 AM	75°F	8:00 AM	83°F	5:00 PM	75°F	10:00 PM	78°F
TUE								
WED								
THU								
FRI								
SAT	6:00 AM	75°F	8:00 AM	75°F	5:00 PM	75°F	10:00 PM	78°F
SUN	6:00 AM	75°F	8:00 AM	75°F	5:00 PM	75°F	10:00 PM	78°F


Programming Your Comfort Interface

Enter Heating Program



1. In Heat mode, press the **Menu** button to display additional button selections.




2. Press **Schedule** button. The display will show the day and period being programmed with the time and temperature. The temperature will be flashing to indicate it can be adjusted.




Programming Your Comfort Interface

3. Press the  or  button to set the temperature for that period.






4. Press the **Time** button and use the  or  button to change the period's start time in 15 minute increments.

Note: If indoor remote sensors are installed proceed to step 5, otherwise skip to step 6.






Programming Your Comfort Interface

5. **FOR INDOOR REMOTE SENSORS ONLY:** Press **Time** again and use the  or  button to deactivate or activate the Comfort Interface's internal temperature sensor. A display showing dashes (--) indicates it has been deactivated. This setting makes your system rely upon the temperature from the remote sensor(s) to control temperature.




Programming Your Comfort Interface

6. Press **Schedule** to advance to the next period. Using the **Time** and  or  buttons, program the remaining periods for that day.




Note: Use the **Copy** button to copy the current day's program to any other day (see page 9).

7. Press **Next Day** and repeat the previous steps to program the remaining days.



Programming Your Comfort Interface

8. Press **Run** to exit programming.




Enter A/C Program

Press **A/C** to place Comfort Interface in air conditioning mode. Set the A/C program following the previous steps for heating.

Using Your Comfort Interface


Operating Your System

Press **Heat** or **A/C** button to select Heating or Cooling. Press **Off** to turn Heating or A/C off.





Operating Your Fan


The **Fan** will run automatically with Heat or Cool. To run the fan continuously, press **Fan** button.



Using Your Comfort Interface


Temporary Program Override

This feature overrides the program temperature setting for a two hour period. Press  or  button to adjust the temperature. The display will show **"Temp Hold"** to the left of the desired temperature. To cancel the temporary setting and return to the program, press **Run**. Example: If you turn up the heat during the morning program, it will automatically return to the programmed temperature two hours later.




Permanent Temperature Hold

The Permanent Temperature Hold feature bypasses the program and holds the temperature indefinitely.

Press the **Hold** button once. The display will show **"Hold"** to the left of the temperature setting. Press  or  button to adjust the temperature you want.

To cancel the permanent hold setting at any time and return to the program, press **Run** button.



Using Your Comfort Interface

Auxiliary Heating

If your heating system is a heat pump, the system activates Auxiliary Heating when the outside temperature is too cold for the heat pump to efficiently heat the home. You can manually activate the auxiliary heating and bypass the heat pump by pressing and holding the **Heat** button until **Aux** changes to **Aux**. To resume heat pump operation without auxiliary press the **Heat** button again.

Dual Fuel Setpoint (requires the outdoor remote sensor and a heat pump with aux gas heat)

This feature turns on auxiliary gas heat and turns off the heat pump when the outdoor temperature falls below the user defined **"Dual Fuel Setpoint"**. To change the **"Dual Fuel Setpoint"**, see further instructions in **"Configuration Menu Options"**, menu # 21, page 23.

Averaging with Indoor Remote Sensor(s)

The Comfort Interface displays the average of the local sensor and any indoor remote sensors unless a device has been deactivated.

System Diagnostics

"Call for Service" will be displayed if your heating or air conditioning system needs a qualified service technician to service the equipment.




Humidification and Dehumidification Control

This feature controls the humidity level inside your home. To change the humidification and dehumidification setpoints, see further instructions in **"Configuration Menu Options"**, menu #s 07 and 08, page 21.

Using Your Comfort Interface


Humidity and Outdoor Temperature Display


The Comfort Interface can be configured to display the current humidity inside your home and/or the current outdoor temperature (if outdoor sensor is installed). When turned on, the display will cycle time, humidity, and/or outdoor temperature. See **“Configuration Menu Options”**, menu #s 11 and 12, page 21.




Using Your Comfort Interface

Replacing Batteries

Replace batteries when “Change ” is displayed.



Pull interface off base




4 “AA” Batteries

Rear view of Comfort Interface


Optional Indoor/Outdoor Remote Sensors

If a sensor is not communicating or the batteries are dead and need to be replaced, the Comfort Interface display will alternately flash time/temperature and remote sensor number (RS1, RS2, RS3 or ORS)/two dashes (--).




Using Your Comfort Interface

Remove cover by holding Remote Sensor base and pressing the tab at the bottom while sliding the cover toward the top.







To Check Battery Status for Sensors:

1. Press the **Menu** button once on the Comfort Interface and release.
2. Press the **Connect** button once and release. Comfort Interface display will indicate **"Searching"** until, (CTL) control is found.









Using Your Comfort Interface

- Continue pressing and releasing the **Next** button to view the battery icon for all remote sensors (RS1, RS2, RS3 or ORS). If battery needs to be replaced the word **"Change"** will be displayed for the remote sensor listed on the screen.





Configuration Menu Options



To enter the menu: Press and hold the **Menu** button for 5 seconds or more. Press the  or  button to change an options's setting. Press the **Next** button to advance to the next menu number. Press the **Menu** button to return to menu # 01.

Menu Number	Displayed (Factory Default)	Press  or  to select options	Descriptions
01	(OFF)	P (partial), L (total lockout)	Select keypad lockout OFF (default) P (partial) - Locks all keys except  and  L (total lockout) - Locks all keys so settings and programs can not be changed without the code.
02	Lockout Code (000)	0 - 999	Selects Keypad Lockout Combination (active only if keypad lockout P (partial) or L (total lockout) is selected).
03	P7	P0	Program per week P7 = 7 days P0 = non-programmable
04	(P4) Morn Day Eve Night	P2	Program periods per day P4 = Morning, Day, Evening and Night P2 = Day, Night (2 is also used for commercial applications).
05	(99) Heat Limit	62° - 99°	Define a maximum heating setpoint Options: 62° - 99°
06	(45) A/C Limit	45° - 82°	Define a minimum cooling setpoint Options: 45° - 82°



Configuration Menu Options

Menu Number	Displayed (Factory Default)	Press  or  to select options	Descriptions
07	(OFF) Hum Setpoint	20 - 60%	Humidifies in heat mode. OFF (default) cancels option. Select Rh setting 20% - 60% to turn on the humidifier if the humidity level is below the humidification setting.
08	(OFF) DeHum Setpoint	40 - 95%	Dehumidifies in cool mode on call for cool. OFF (default) cancels option. Select Rh setting 40% - 95%. When room humidity is above the selected setting the DHM terminal(s) will de-energize to lower the fan speed whenever there is a call for cool. Air speed reduction across the cooling coil allows it to condense removing more humidity.
09	(OFF) Change Filter	1 - 12 months	Displays reminder to change filter after a selected number of months.
10	(OFF) Change Pad Hum	1 - 12 months	Displays reminder to change humidifier pad after a selected number of months.
11	Humidity (OFF)	ON/OFF	Select humidity display on screen On/OFF
12	Outdoor (OFF)	ON/OFF	Only if outdoor sensor is available. Turns on or off the home screen outdoor temperature display

Configuration Menu Options

Menu Number	Displayed (Factory Default)	Press  or  to select options	Descriptions
13	(OFF) OF	1 hr - 3 hr	Occupancy Fan This feature is used in light commercial applications and will turn on the fan 1, 2 or 3 hours before the Day schedule begins and will keep the fan on during the Day schedule. This item appears only when program periods per day is set to P2 (see menu item 4).
14	(ON) E	ON/OFF	Selects Energy Management Recovery On or Off (not available if set as Non-Programmable). ON Starts program earlier than the program time. OFF cancels feature
15	0 (Temperature)	± 5°	Adjusts the temperature displayed on the Comfort Interface by an off set.
16	(ON) LS	ON/OFF	"OFF" turns the sensor in the Comfort Interface off. The room temperature display will come from the remote sensor(s) only. If no wireless remotes are installed, this step is skipped.
17	(OFF) b	ON/OFF	"ON" beeps when any button is pushed. "OFF" cancels the beep.
18	(ON) dL	ON/OFF	"ON" will turn the backlight on momentarily after any key is pressed. "OFF" cancels backlight.
19	(°F)	°F/°C	Selects display temperature units in °F (Fahrenheit) or °C (Celsius)
20	0%	-20% to + 20%	Displays the room humidity with an offset default 0%. The setting can be changed from -20 LO to 20 HI. The displayed humidity will change as the offset is changed.

Configuration Menu Options

Menu Number	Displayed (Factory Default)	Press  or  to select options	Descriptions
21	Outdoor OFF (dF)	5° - 50°	Selecting an outdoor temperature from 5° to 50° turns on the Dual Fuel setpoint. As long as the outside temperature is above the setpoint, the compressor will operate. When the temperature drops below the setting, the Comfort Interface will start the gas heat and turn off the compressor. This item appears only if HP1 or HP2 is selected and outdoor sensor is installed and enabled.
22	L 5 dF	0 - 9	Select a number 1 - 9 to activate the "logic" heat pump Dual Fuel option (no outdoor remote sensor required). This causes the Comfort Interface to turn off the heat pump shortly after the furnace fires. Five (5) is the factory recommended average setting. A lower number slightly increases the delay between heat pump and furnace stages. A higher number slightly decreases the delay between heat pump and furnace stages. Note: This setting is not minutes or degrees. It is a numeric setting that will influence the internal Comfort Interface calculation for staging.
23	(80) AO	35° - 80°	Selects Auxiliary Heat Cut out temperature. If the outdoor temperature is above the selected setting, the auxiliary heat will not turn on. This item appears only if HP1 or HP2 is selected and outdoor sensor is installed and enabled.

Press **Run** to exit menu

NOTES

Homeowner Help Line

In North America: 800-284-2925

En Español: 888-725-9797

In Australia: 1800 057 587

Hours of Operation

North America (CST) U.S., Canada & Mexico

7 am to 1 am Monday – Friday

7 am to 4 pm Saturday – Sunday

Australia (Eastern Standard Time)

9 pm to 3 pm Monday – Friday

9 pm to 6 am Saturday – Sunday

Additional Product information can be viewed at

<http://www.emersonclimate.com/en-US/products/thermostats/Pages/thermostats.aspx>

or <http://www.white-rodgers.com>

White-Rodgers is a division
of Emerson Electric Co.

The Emerson logo is a
trademark and service mark
of Emerson Electric Co.

Part No. 37-7236A

1127

White▼
Rodgers™

www.white-rodgers.com
www.emersonclimate.com


EMERSON™
Climate Technologies