



UI Upgrade Instructions

for Wi-Fi Dehumidifiers

Instructions for replacing the standard UI with a Wi-Fi-Enabled UI on e-Series Dehumidifiers (Models E070, E080, E100, E130)

1. Disconnect power to the dehumidifier.
2. Remove the filter access door and filter.
3. Remove the four screws holding the user interface to the cabinet (whether the UI is on the top or end panel). See **FIGURE 1**.
4. Pull user interface out of unit through filter door hole and unplug the 3-wire harness from the back. See **FIGURE 2**.
5. Plug the harness into the new Wi-Fi model. See **FIGURE 3**.
6. Return user interface to position from inside the unit.
7. Replace the screws, but do not overtighten. See **FIGURE 4**.
8. Re-insert the filter and filter access door.
9. Restore power to the dehumidifier.

