

## TECHNICAL DETAILS

### KIT-OSA-INS-5

BASIC INSTALLATION KIT FOR ERV AND HRV, 5 IN. (127 MM) DUCTS



#### INCLUDES

- 2 x Air intake/Exhaust vent Ø 5 in.
- 2 x Round air diffuser with collar Ø 5 in.
- 2 x 25 ft. Non-insulated flexible duct Ø 5 in.
- 25 ft. Insulated flexible air duct Ø 5 in.
- 8 x 24 in. Tie wrap

### KIT-OSA-INS-6

BASIC INSTALLATION KIT FOR ERV AND HRV, 6 IN. (152 MM) DUCTS



#### INCLUDES

- 2 x Air intake/Exhaust vent Ø 6 in.
- 2 x Round air diffuser with collar Ø 6 in.
- 2 x 25 ft. Non-insulated flexible duct Ø 6 in.
- 25 ft. Insulated flexible air duct Ø 6 in.
- 8 x 24 in. Tie wrap

### KIT-SA-FI-115

KIT OF 2 FILTERS FOR ERV 115R



#### INCLUDES

- 2 Merv8 charcoal polyester filters

### KIT-SA-FI-230

KIT OF 2 FILTERS FOR ERV 230R




#### INCLUDES

- 2 Merv8 charcoal polyester filters

### KIT-SA-FI-150

KIT OF 2 FILTERS FOR ERV AND HRV 150R



#### INCLUDES

- 2 Merv8 washable polyester filters